

E1SL SDK EVO LK EVO KS EVO

EN

Instructions valid starting from the FW updates supplied with ZIPACK 4.5.0.

The FAAC logo is rendered in a bold, black, sans-serif font. The letters 'F' and 'A' are connected at the top, and the 'A' has a distinctive shape with a diagonal stroke. The 'C' is a simple, rounded letter. The logo is positioned in the bottom right corner of the page, partially overlapping a large, light gray graphic element that resembles a stylized 'F' or a series of horizontal bars with diagonal ends.

FAAC

FAAC S.p.A. Soc. Unipersonale

Via Calari, 10 - 40069 Zola Predosa BOLOGNA - ITALY

Tel. +39 051 61724 - Fax +39 051 09 57 820

www.faac.it - www.faacgroup.com

CONTENTS

1. ELECTRONIC MODULE E1SL 4
 Board E1SL 4
 Status LEDs on the board 5
 Terminal boards and connectors 5

2. DM BOARD 6
 Installing the DM board 6
 Connecting the second motor 6
 Enabling the DM KIT 6

3. OPERATING MODE (MODFUN) 8

4. CONNECTIONS 9

5. CONFIGURABLE INPUTS 10
 Connections 10
PROGRAMMING 10
 Automatic Opening Inputs 11
 SEMI-AUTOMATIC OPEN input 11
 Safety inputs 11
 Operating mode inputs 11
 TIMER input 11
 RESET input 11

6. CONFIGURABLE OUTPUTS 12
PROGRAMMING 12
 Connections 12

7. START-UP 13
 Start-up procedure 13
 7.1 Turn power on to the board 13
 7.2 Set the model of the automation and the DEFAULT 13
 7.3 Perform the SETUP 13
 7.4 Programming the board 14
 7.5 Movement parameters 19
 7.6 Obstacle detection 19
 7.7 Low Energy 19
 7.8 Intrusion: KEEP CLOSED/PULL&GO 19
 7.9 Energy Saving 19
 7.10 Timing and partial opening 19
 7.11 Date and Time 20
 7.12 Counters 20
 Cycle counter - Scheduled maintenance 20
 SAFE FLOW 20
 7.13 TIMER 20
 WEEKLY PROGRAMMING 20
 JOLLY PROGRAMMING 20
 ENABLING/DISABLING THE TIMER 21

8. ACCESSORIES 21
 Emergency battery 21
 XB LOCK motor block and monitoring (optional) 22
 XM LOCK motor block and monitoring 23
 ELASTIC Kit 23
 One Dual Technology entry and exit detector 24
 2 Dual Technology entry and exit detectors 25
 Infrared detector for safety in opening 26
 XFA button photocells 27

9. INTERCOM 28
 Installing INTERCOM 28
 Operating mode 28
 Boards in maintenance 28
 INTERCOM diagnostics 28
 INTERLOCK, INTERLEAVES, AIRSLIDE 28

9.1 INTERLOCK 29
 Installing INTERLOCK 29
 Enabling / disabling INTERLOCK 29

9.2 AIRSLIDE 30
 Installing AIRSLIDE 30

9.3 INTERLEAVES 31
 Installing INTERLEAVES 31

10. FW UPDATES AND FILE DOWNLOAD - USB 32
 AutoUpdate 32
 Upload/Download Menu 32
 Bootloader and FW versions 32


11. DIAGNOSTICS 33
 LEDs on the board 33
 FW versions 34
 Automation and configured inputs status 34
 Errors and WARNINGS 34

11.1 Reset 37

11.2 Restoring factory settings 38
 Restoring default settings 38



















12. LK EVO 39

13. KS EVO 41

14. SDK EVO 42
 SDK EVO lock device 42
 Home page 43
 Reset - Lock/Release 43
 PASSWORD (PSW) 43
 MODFUN 44
 MENU  44
PROGRAMMING 44
 Menu 1 language 47
 Menu 2 Programming 47
 Menu 3 ERRORS 48
 Menu 4 WARNINGS 48
 Menu 5 COUNTERS 48
 Menu 6 DATE / TIME 49
 Menu 7 TIMER 49
 Menu 8 PASSWORD 49
 Menu 9 INFO 49

15. SIMPLY CONNECT 50

TABLES

 **1** Assigning the Operating mode 8
 **2** Configurable inputs - DEFAULT 10
 **3** Configurable inputs - AVAILABLE SETTINGS 10
 **4** Configurable outputs - DEFAULT 12
 **5** Configurable Outputs - AVAILABLE SETTINGS 12
 **6** BASIC Programming 15
 **7** ADVANCED programming 17
 **8** Upload/Download Menu 32
 **9** Status of the automation 34
 **10** Errors, Alarms/Info codes 35
 **11** Bootloader (BO) Error codes 37
 **12** Troubleshooting guide 38
 **13** LK EVO Operating buttons 39
 **14** LED Error Coding on Function selectors 40
 **15** LED Warning coding - LK EVO 40
 **16** FW version LED coding - LK EVO 40
 **17** SDK EVO - FUNCTIONS menu  45


1. ELECTRONIC MODULE E1SL

The E1SL electronic module is designed to control FAAC automation models A1000, A1400 AIR, RKE 1400, SF1400, GBF1500. The installation instructions must be followed.


Motorised pedestrian doors fall within the scope of the type "C" harmonised European Standard EN 16005:2012. It is assumed that automation systems manufactured in accordance with this standard also comply with the essential safety requirements of the Directive 2006/42/EC.

This however does not exempt the manufacturer from carrying out a risk analysis in order to implement appropriate measures for those


risks that are not covered by the standard or by the manufacturers of the components. FAAC S.p.A. recommends that you always comply with the EN 16005:2012 standard and in particular that you adopt the criteria and safety devices indicated, without exception.



Fuses		
F1 battery protection	8 A F (quick)	
F2 accessory protection	2 A F (quick)	
F3 power supply unit primary protection	2.5 A T (delayed) 5x20 mm	




BOARD E1SL



Buttons	
SW1	SETUP (pressed for 5 s) / RESET (pressed momentarily)
- (SW2)	scrolls programming values
+ (SW3)	scrolls programming values , when not in programming mode, performs AUTOMATIC OPENING (pressed for 1 s)
F (SW4)	programming: scrolls functions/confirms values



STATUS LEDS ON THE BOARD




LED	Description
MAIN	BLUE main power supply unit input
DL2	BLUE board power +5V
DL11	BLUE accessories power (+24 V ~)
USB	GREEN USB storage device
ERR	RED error or alarm
BAT1	RED battery status
BAT2	GREEN battery charger status
SIC_OP	RED safety in opening
SIC_CL	RED safety in closing
EMERG	GREEN emergency command
OPEN	GREEN OPEN command

SIC_OP and SIC_CL lit simultaneously = safety STOP



TERMINAL BOARDS AND CONNECTORS



J1	Removable terminal board configurable inputs S1	J14	Connector for emergency battery
J4	Removable terminal board configurable inputs S2	J17	USB port
J7	Removable terminal board configurable inputs E1, E2	J18	Removable terminal board INTERCOM
J8	Removable terminal board keypad or EVO functions selector	J21	Removable terminal board configurable inputs I1, I2, I3, I4
J9	Removable terminal board for button photocells	J22	Removable terminal board configurable outputs O1, O2
J10	Connector for main power supply 36 V, 4 A	J23	Connectors for Simply Connect (accessory device)
J11	Connector for motor M1	J25	Connector for motor block and monitoring
J12	Connector for motor M1 encoder	J26	Jumper INTERCOM
J13	Connector for motor block and monitoring		



2. DM BOARD

A DM board must be installed on automations fitted with a double motor.

INSTALLING THE DM BOARD



Before proceeding, disconnect the mains power supply and disconnect the emergency battery (if present).

1. Remove the E1SL board: remove all the connections, the screw (1) and the screw with washer (2), then remove the board from the support (3).
2. Unscrew the 2 screws (4) and remove the plastic cap, pulling out the 2 pins (5).
3. **Install the DM board** Refer to [6](#), install the 4 posts (6) on the E1SL board and fasten them using the screws provided (7). Insert the 2 comb connectors into the connectors of the E1SL board as far as the connector (8). Insert the DM board (9) on the side opposite the comb connectors, as far as the connector (8). Fasten the DM board onto the 4 posts using the screws provided (10).
4. Replace the plastic cap, inserting the 2 pins (5) into the board E1SL. Fasten it using the 2 screws (4).
5. With reference to [5](#), Reinstall the E1SL board into theseats (3). Fix in position with the screw (1) and the screw with washer (2). **IMPORTANT:** the washer provides the board's earth connection.
6. Restore all connections.

CONNECTING THE SECOND MOTOR

1. Extend the motor cable using the cable with connector and the terminal connector provided.
2. With reference to [7](#), insert the connector (11) onto the board DM (12). Follow the colour coding of the wires.

ENABLING THE DM KIT

During programming:


- from Board, advanced programming: $\text{d} \square = \text{5}$

or


- from SDK EVO:

$\text{P}/\text{PROGRAMMING}/\text{INSTALLATION}/\text{2ND ENGINE KIT} = \text{ENABLED}$



Removing/reinstalling the E1SL board



Removing/reinstalling the cap




Installing the DM board



6

2nd MOTOR connection



7

ENGLISH
Translation of the original instructions

3. OPERATING MODE (MODFUN)

The operating mode of the automation can be assigned using the devices shown in the table on this page (Assigning the Operating mode) and from the TIMER (TIMER § Section).

Note: if more than one device is used to assign the operating mode, the order of priority is: TIMER, Configured input, Function selector (KS EVO, LK EVO, SDK EVO).

■ **AUTOMATIC mode**

The automation CLOSES AUTOMATICALLY after the programmed pause time.

When not in programming mode, the command can also be executed by pressing the + BUTTON for 1 s.

TWO-DIRECTIONAL Two-directional transit is allowed (Internal Opening and External Opening enabled).

EXIT ONLY Only exiting is allowed (External open disabled).

ENTRY ONLY Only entry is allowed (Internal Open disabled).

■ **AUTO MANUAL mode**

The automation allows MANUAL OPENING and CLOSES AUTOMATICALLY after the set pause time.

■ **MANUAL mode**

The leaves are free to move and may only be manually operated. No command is active.

Before exiting from this mode, make sure that the leaves can be moved safely. When you exit from MANUAL mode, the board will carry out a RESET.

■ **OPEN mode**

The automation opens and remains open.

■ **NIGHT-TIME mode**

The automation closes and remains closed. External Opening is disabled. Internal Opening is enabled only in the time interval programmed as NIGHT-TIME MODE DELAY. It can only be opened via Key, Emergency Opening and Pharmacy open inputs (with automatic closing after the NIGHT PAUSE time).

■ **INTERLOCK mode**

The opening of one automation is subject to the closing of another (§ INTERLOCK Section). INTERLOCK can be selected for TWO-DIRECTIONAL transit, ENTRY ONLY, or EXIT ONLY.

1 Assigning the Operating mode

Function (*) = NOT available for SF1400 and GBF1500	SDK EVO	LK EVO/KS EVO	Programming the configurable input
AUTOMATIC TWO-DIRECTIONAL	TOTAL		-
	PARTIAL (*)		45
AUTOMATIC EXIT ONLY	TOTAL		41
	PARTIAL (*)	-	-
AUTOMATIC ENTRY ONLY	TOTAL	-	42
	PARTIAL (*)	-	-
AUTO MANUAL	TOTAL	-	47
	PARTIAL (*)	-	-
MANUAL			44
OPEN	TOTAL		40
	PARTIAL (*)	-	-
NIGHT	TOTAL		43
	PARTIAL (*)	-	-
INTERLOCK TWO-DIRECTIONAL	TOTAL	-	46
	PARTIAL (*)	-	-
INTERLOCK EXIT ONLY	TOTAL	-	-
	PARTIAL (*)	-	-
INTERLOCK ENTRY ONLY	TOTAL	-	-
	PARTIAL (*)	-	-

4. CONNECTIONS

RISKS



PERSONAL PROTECTIVE EQUIPMENT



REQUIRED TOOLS




Before working on the board, always turn off the mains power supply and disconnect the emergency battery (if present). Turn the power back on only after completing all the electrical connections and carrying out the preliminary start-up checks.



The maximum total load of accessories connected to the board (+24 V \Rightarrow) must not exceed 1A (except SDK EVO).

1. The motor M1 must be connected to connector J11.
2. The encoder must be connected to connector J12.
3. A DM board must be installed on automations fitted with a double motor in compliance with the instructions provided in the specific § chapter.
4. For connecting additional devices, where present, please refer to the specific chapters:
 - XB LOCK or XM LOCK motor block
 - XFA button photocells
 - XV1 or XDT1 detectors, single or double, exit and entry, for opening and safety in closing
 - XBFA ON detectors for safety in opening
 - Configurable inputs
 - Configurable outputs
 - LK EVO, KS EVO, SDK EVO function selectors

Motor M1 and encoder connection



5. CONFIGURABLE INPUTS

Configurable inputs have an assigned function (☒ Configurable inputs - DEFAULT), which is modifiable in programming (☒ Configurable inputs - AVAILABLE SETTINGS). Some functions vary if the Energy Saving is active (relative § Section).

CONNECTIONS

Only connect devices with a volt free contact to configurable inputs. The contact of the device must be connected between the input and GND.

I1, I2, I3, I4 (TERMINAL BOARD J21)

V	+24 V	accessories power supply
I4	Configurable input I4	
I3	Configurable input I3	
G	GND	Accessories power supply negative and Common contacts
I2	Configurable input I2	
I1	Configurable input I1	
G	GND	Accessories power supply negative and Common contacts
V	+24 V	accessories power supply

S1 (TERMINAL BOARD J1), S2 (TERMINAL BOARD J4)

T	TEST	
G	GND	Power supply negative and Common contacts
S1	Configurable input S1	
G	GND	Power supply negative and Common contacts
V	+24 V	accessories power supply

T	TEST	
G	GND	Power supply negative and Common contacts
S2	Configurable input S2	
G	GND	Power supply negative and Common contacts
V	+24 V	accessories power supply

E1, E2 (TERMINAL BOARD J7)

E2	Configurable input	
G	GND	Accessories power supply negative and Common contacts
E1	Configurable input	

PROGRAMMING

For the available options, see the table ☒ Configurable inputs - AVAILABLE SETTINGS and the subsequent sections. The input is activated according to how the contact logic is programmed:

NO = the input activates when the contact closes

NC = the input activates when the contact opens

- from Board:

Basic Programming for the inputs of terminal board J21. Advanced Programming for the inputs of terminal boards J1, J4 and J7.

The default contact logic can only be modified via the SDK EVO. The test (IF, 2F ...) is only available for the inputs configured as Opening Safety, Closing Safety and Safety STOP.

- from SDK EVO:

☒ /PROGRAMMING/INPUTS/OUTPUTS ...

...INPUTS I1-I4, S1-S2, E1/E2 (select the input)

...FUNCTION (assign the function no...61)

...NO/NC (the contact logic must be programmed according to the type of contact of the device)


...TEST (available for inputs configured as Safeties)

☒ 2 Configurable inputs - DEFAULT

Input (terminal board)	Default Programming	Board function: (default)
I1	External OPENING (NO)	C1 (I)
I2	Internal OPENING (NO)	C2 (4)
I3 (J21)	KEY (NO)	C3 (IO)
I4	Automatic Opening (NO)	C4 (7)
S1 (J1)	Closing Safety EXT (NC) TEST enabled	P1 (24) IF (5)
S2 (J4)	Closing Safety INT (NC) TEST enabled	P2 (25) 2F (4)
E1 (J7)	not enabled	E1 (no)
E2 (J7)	not enabled	E2 (no)

☒ 3 Configurable inputs - AVAILABLE SETTINGS

from SDK EVO	from Board
input NOT enabled	no
EXTERNAL OPENING	1 (NO)
INTERNAL OPENING	4 (NO)
AUTOMATIC OPENING	7 (NO)
SEMI-AUTOMATIC OPENING	8 (NO)
PHARMACY OPEN (NOT for SF1400 and GBF1500)	9 (NO)
KEY	10 (NO)
PARTIAL OPEN (NOT for SF1400 and GBF1500)	11 (NO)
CLOSING SAFETY (TEST available)	20 (NC)
OPENING SAFETY (TEST available)	21 (NO)
SAFETY STOP (TEST available)	23 (NC)
EXTERNAL CLOSING SAFETY (TEST available)	24 (NC)
INTERNAL CLOSING SAFETY (TEST available)	25 (NC)
EMERGENCY OPENING	30 (NC)
EMERGENCY OPENING with MEMORY	31 (NC)
EMERGENCY STOP	32 (NC)
EMERGENCY STOP with MEMORY	33 (NC)
EMERGENCY CLOSING	34 (NC)
EMERGENCY CLOSING with MEMORY	35 (NC)
EMERGENCY BREAK OUT	37 (NC)
TOTALLY OPEN	40 (NO)
AUTOMATIC EXIT ONLY TOTAL	41 (NO)
AUTOMATIC ENTRY ONLY TOTAL	42 (NO)
NIGHT TOTAL	43 (NO)
MANUAL	44 (NO)
AUTOMATIC TWO-DIRECTIONAL PARTIAL (NOT for SF1400 and GBF1500)	45 (NO)
INTERLOCK TWO-DIRECTIONAL TOTAL	46 (NO)
AUTO MANUAL TOTAL	47 (NO)
TIMER	60 (NO)
RESET	61 (NO)



AUTOMATIC OPENING INPUTS

When one of the following inputs is activated, the automation opens and closes again after the pause time. The automation does not close as long as the input is active.

EXTERNAL OPENING (1) Input specifically for external control devices. The input is disabled in NIGHT-TIME or EXIT ONLY mode.

INTERNAL OPENING (4) Input specifically for internal control devices. The input is disabled in ENTRY ONLY mode. In NIGHT-TIME mode, the input is enabled only in the time interval programmed as NIGHT-TIME MODE DELAY.

AUTOMATIC OPENING (7) The input is disabled in NIGHT-TIME mode (it is enabled in EXIT ONLY and ENTRY ONLY mode).

PHARMACY OPEN (9) In NIGHT mode, the command opens the leaves to the percentage programmed in PARTIAL PHARMACY. The input opens the leaves automatically in the other operating modes.

KEY (10) Command also enabled in NIGHT-TIME mode.

PARTIAL OPEN (11) Partially opens the automation to the programmed percentage. It is NOT enabled in the NIGHT mode.

SEMI-AUTOMATIC OPEN INPUT

(8) When the input is activated with the automation closed, the automation opens (TOTAL or PARTIAL according to the operating mode selected) and remains open. When the input is activated with the automation open, it closes it.

The input is NOT active in NIGHT-TIME mode.

SAFETY INPUTS



Use monitored safety devices that are compliant with standard EN 16005:2012 on inputs configured for safety functions.

On the inputs configured as Safeties, the Test to make sure that the automation works correctly must be enabled before movement takes place. If the test isn't passed, movement is inhibited (TEST ERROR). Alternatively, from SDK EVO it is possible to enable movement in Low Energy mode.

🔧/PROGRAMMING/MISCELLANEOUS/TEST ERROR

ENABLED = movement inhibited

DISABLED = movement in Low Energy mode

CLOSING SAFETY (20) Connect the closing safety devices. When this input is activated:

- during closing, the automation reverses the movement
- when the automation is open, it prevents it from closing
- when the automation is paused, it resets the pause time

OPENING SAFETY (21) Connect the opening safety devices. When the input is activated during opening, the effect depends on the programming:

STOP the movement stops until the safety in opening is disengaged; it then continues to open

Low Energy the movement slows down until fully open

- from Board Advanced Programming: (1 = STOP 2 = Low Energy)
- from SDK EVO: 🔧/PROGRAMMING/MISCELLANEOUS/OPENING SAFETY FUNC.

SAFETY STOP (23) When this input is activated, the automation stops and remains stopped. When the input is deactivated, it starts to move again. In NIGHT-TIME mode, the movement stops, and when disengaged the automation closes.

EXTERNAL CLOSING SAFETY (24) As CLOSING SAFETY (20) but intended exclusively for the detector located outside the premises.

INTERNAL CLOSING SAFETY (25) As CLOSING SAFETY (20) but intended exclusively for the detector located inside the premises.

EMERGENCY INPUTS

The EMERGENCY inputs have priority over any other input, in any NON MANUAL operating condition and mode.

If more than one EMERGENCY input is activated that have different configurations, the order of priority is: Emergency Opening, then Emergency Stop, then Emergency Closing.

- Programmed input WITH NO MEMORY: when the status of the input is restored, the automation starts to operate normally again.

- Programmed input WITH MEMORY: when the status of the input is restored, a RESET has to be carried out in order for the automation to start operating normally again.

EMERGENCY OPENING (30, 31) When the input is activated, the automation opens (always TOTAL opening) and remains open as long as the emergency is active.

EMERGENCY STOP (32, 33) When the input is activated, the automation stops and remains stopped as long as the emergency is active.

EMERGENCY CLOSING (34, 35) When the input is activated, the automation closes and remains closed as long as the emergency is active.

EMERGENCY BREAK OUT (37) When the input is activated following the breakout of the APN, an automation reset is activated: slow opening and re-engagement of the leaves. After 10 s, the board restores the operation of the automation.

OPERATING MODE INPUTS

These inputs allow an operating mode to be selected (§ specific Section). When the input is deactivated, the automation reverts to the mode that was previously selected.

Operating mode order of priority: Manual (44), Night Total (43), Open Total (40), Automatic Exit Only Total (41), Automatic Entry Only Total (42), Automatic Two-directional Partial (45), INTERLOCK Two-directional Total (46), Auto Manual Total (47).

TIMER INPUT

(60) When the input is activated, TIMER programming is enabled, which automatically assigns the operating mode to the programmed time bands. When the input is deactivated, the TIMER programming is disabled.

RESET INPUT

(61) This input carries out a RESET (§ Specific section).

6. CONFIGURABLE OUTPUTS

The configurable outputs allow warnings to be generated from the board under certain conditions. These outputs have an assigned function (🔲 Configurable outputs - DEFAULT), which are modifiable in programming.

Carry out the programming, then make the connections.

PROGRAMMING

For the available options, see the table 🔲 Configurable outputs - AVAILABLE SETTINGS and subsequent sections.

The output is activated according to how the contact logic is programmed:

- NO = the contact closes when the output is active
- NC = the contact opens when the output is active

- from Board Advanced Programming: 01, 02. The contact logic is assigned by Default.

or

- from SDK EVO: /PROGRAMMING/INPUTS/OUTPUTS ...
- ...OUTPUTS 01/02 (select the output)
- ...FUNCTION (select no, 1...15)
- ...NO/NC (the output contact logic has to be programmed)

DISABLED (0)

GONG (1) indicates that at least one input configured as safety in closing/Stop is active. Indicated at 1 s intervals.

ERROR (2) indicates an error, or INTRUSION in NIGHT-TIME mode, or a LOCK fault in NIGHT-TIME mode event is active.

BATTERY (3) indicates that the automation is operating on the battery, as there is no mains power.

EMERGENCY ACTIVE (4) indicates that at least one input configured as emergency is active.

SAFETIES TEST (5) carries out a test on the devices connected to the inputs configured as Safeties and with TEST enabled.

DOOR NOT CLOSED (6) indicates that the automation is NOT closed.

DOOR OPEN (7) indicates that the automation is open.

DOOR MOVING (8) indicates that the automation is moving.

LIGHT (9) switches on the courtesy light when the automation starts to open. The output remains active for 60 s (time can be modified via the SDK EVO up to 240 s).

INTRUSION ACTIVE (10) when the automation is closed, indicates an unexpected opening (the encoder detects a movement of more than 1 cm).

CLOSING SAFETY (11) indicates that at least one Safety in Closing is active.

SAFETIES (12) indicates that at least one Safety in Closing or Opening is active.

AIRSLIDE SP1 (13) indicates that the air is activated at speed SP1 when the AIRSLIDE is in manual.

AIRSLIDE SP2 (14) indicates that the air is activated at speed SP2 when the AIRSLIDE is in manual.

LOCK (15) indicates that the Motor block is on.

Simply Connect (16) indicates that the programming is in progress from Simply Connect.

TIMER (17) signals that a TIMER mode function is in progress.

PEOPLE IN NUMBER (18) indicates that the programmed number of people in the premises has been reached.

TRAFFIC LIGHT EXT (19) activates RED to authorize the passage of one person at a time and when the maximum programmed number of people has been reached.

TRAFFIC LIGHT INT (20) activates RED to authorize the passage of one person at a time.

LOW BATTERY (23) indicates that the charge level of the emergency battery is too low for the movements to be carried out.

NIGHT (24) indicates that the door is in NIGHT mode.

CONNECTIONS

Do not exceed the maximum load indicated. If you use output 01, connect the device to 01 and V.

01, 02 (TERMINAL BOARD J22)


	02 02	Relay contact output OUT2 Max load 2A +24 V==
	01	Open Collector output OUT1 Max load 100 mA
	G	GND Accessories power supply negative and Common contacts
	V	+24 V== accessories power supply

🔲 4 Configurable outputs - DEFAULT

Exit (terminal board)	Default programming	Board function and (default) (advanced programming)
01 (J22)	DOOR NOT CLOSED (NO)	01 (6)
02	ERROR/BOARD FAILURE (NO)	02 (2), (23) if dF=2

🔲 5 Configurable Outputs - AVAILABLE SETTINGS

SDK EVO function	Board value and (default):
Disabled	0
GONG	1 (NO)
ERROR	2 (NO)
BATTERY	3 (NO)
EMERGENCY ACTIVE	4 (NO)
SECURITIES TEST	5 (NC)
DOOR NOT CLOSED	6 (NO)
DOOR OPEN	7 (NO)
DOOR MOVING	8 (NO)
LIGHT	9 (NO)
INTRUSION ACTIVE	10 (NO)
CLOSING SAFETY DEVICE	11 (NO)
SAFETIES	12 (NO)
AIRSLIDE SP1	13 (NO)
AIRSLIDE SP2	14 (NO)
LOCK	15 (NO)
Simply Connect	16 (NO)
TIMER	17 (NO)
PEOPLE IN NUMBER	18 (NO)
TRAFFIC LIGHT EXT	19 (NO)
TRAFFIC LIGHT INT	20 (NO)
BATTERY LOW	23 (NO)
NIGHT	24 (NO)



7. START-UP

RISKS PERSONAL PROTECTIVE EQUIPMENT



START-UP PROCEDURE

CARRY OUT THE FOLLOWING PRELIMINARY CHECKS. Disconnect the mains power supply and disconnect the emergency battery (if present) and the motor(s). Move the leaves manually to make sure that they move smoothly and without friction. When finished, reconnect the motor(s).

Make sure that the ENCODER connector has been inserted correctly.

Then, carry out the operations described in the following sections in order.

1. Turn power on to the board.
2. Set the model of the automation and the DEFAULT.
3. Perform the SETUP.
4. Program the board for the required functions.
5. Make sure that the automation works correctly in the required operating modes, with all the devices installed (control devices, safety detectors, function selectors and devices connected to the inputs and outputs).
 - For doors in Low Energy mode, make sure that the forces generated by the leaf are within the limits permitted by legislation. Use an impact force tester in accordance with standard EN 16005:2012. For non-EU countries, if there are no specific local regulations, the static force must be less than 67 N.
 - For doors that are not in Low Energy mode, make sure that the test object is detected in all areas affected by the door movement.
6. Once the start-up has been completed, we recommend that you save the complete configuration for the automation by using the DOWNLOAD option (§ Menu Upload/Download).

■ INTERCOM (if provided)

Complete the start-up procedure for each automation before setting up an INTERCOM network. Only afterwards connect the boards to the network, carry out the programming and enable INTERCOM (§ specific section).

7.1 TURN POWER ON TO THE BOARD

1. Turn the mains power back on.
2. Connect the emergency battery (if present).
When first switched on, the following appear on the display of the main board and the SDK EVO (if used):

Board display	SDK EVO display
b□	Bootloader 0.3 (example)
(Bootloader phase)	(SDK EVO Bootloader version)
4.5 (example)	4.2 version (example)
(E1SL FW version)	(SDK EVO FW version)
L□ flashing light	ERROR 39 flashing
(the board requires SETUP)	(the board requires SETUP)

3. Check the input status LEDs on the board and for the presence of ERRORS (§ Diagnostics Section).

7.2 SET THE MODEL OF THE AUTOMATION AND THE DEFAULT

- from board Basic programming: CF Set the model of the automation
dF Set the DEFAULT
- from SDK EVO: /PROGRAMMING/DOOR TYPE...
For FHE SLIDING select the model RKE 1400
For SF1400 requires you to set the Leaf number and passage opening:
- from board Basic programming: CF=4 L_n=1 o₂ e L_t=1 o₂ o₃

- from SDK EVO: /PROGRAMMING/DOOR TYPESF1400
...1LEAF or 2LEAVES
...SELECT PASSING SPACE

To load the DEFAULT:

- /PROGRAMMING/MISCELLANEOUS/DEFAULT CONFIG
- DO YOU WANT TO LOAD DEFAULT CONFIG 1? Press OK to confirm, or change option (↑ ↓). DO YOU WANT TO LOAD DEFAULT CONFIG 2?

- DOUBLE MOTOR** for automations with a double motor, enable the Double Motor Kit:
 - from board Advanced Programming: dF=3
 - from SDK EVO: /PROGRAMMING/INSTALLATION/2ND ENGINE KIT Enabled

7.3 PERFORM THE SETUP

The SETUP procedure consists of a series of movements during which the board acquires the travel of the leaves and other mechanical parameters.

THE SYSTEM NEEDS TO BE SETUP

- when L□ flashes on the display (e.g. when the automation is first put into operation, or after the board has been replaced, or after factory settings have been restored)
- if the number of leaves is changed
- when you wish to modify the length of travel of the leaves, or the automation model, or the direction of rotation of the motor, or for enabling/disabling the DM KIT
- when the number of leaves or the passage opening has been modified on SF1400

The inputs configured as safeties are ignored during SETUP. To prevent any hindrance to motion or injury to people, keep at a distance and prevent anyone from going near the system.

1. Run the SETUP (the position of the door is irrelevant):
 - from board: press the button SW1 for approximately 5 s, release when movement starts
 - from SDK EVO: /PROGRAMMING/INSTALLATION/START SETUP OK
2. The SETUP is carried out automatically. Make sure that the movement being carried out corresponds with the SETUP phase on the display.

MOTOR ROTATION If the movement does not correspond with the phase shown on the display, when the SETUP has been completed, invert the direction of rotation of the motor and then repeat the SETUP.

- from board Basic programming: r□
- from SDK EVO: /PROGRAMMING/INSTALLATION/MOTOR ROTATION select STANDARD or NOT STANDARD

3. SETUP ends with OPENING, then the automation is ready to use. If the SETUP procedure fails, L□ flashes on the display. Resolve any ERRORS there may be (see Section § Diagnostics), then run a new SETUP.

The following are reasons for the SETUP procedure NOT being carried out or being interrupted: NIGHT or MANUAL mode, operating on battery due to lack of mains power, emergency Inputs active.

SETUP from board

SETUP phases on the display

- L□ flashing = the board requires you run the SETUP
- L1 flashing = closing in SETUP
- L2 flashing = opening in SETUP
- 2 or □3 automation ready for operation

7.4 PROGRAMMING THE BOARD

Programming can be carried out from the BOARD, using the +, -, F buttons, from the SDK EVO or via Simply Connect. For programming via Simply Connect see the specific manual.

- Programming from the SDK EVO/Simply Connect offers a wider number of options. If values have been programmed that are not available on the board, the board display indicates them all with the value EP (External Program). Programming from the board can anyway modify values indicated by EP, but it is not able to restore them.

SDK EVO can disable programming from the board:

/PROGRAMMING/MISCELLANEOUS/BOARD'S DISPLAY BLOCKED or NOT BLOCKED

PROGRAMMING FROM THE BOARD

The E1SL has two Programming Menus: Basic and Advanced (relative Table).

■ BASIC programming

1. When the display indicates the status of the automation, press and hold down the **F** button: the display shows the first function (30).

Each function will be displayed for as long as button F remains pressed.

2. Release button **F**: the display shows the value of the function.

3. When the display indicates the value of the function, press the + or - button to modify it.

4. Press button **F** to confirm and go to the next function. The modified value becomes effective immediately.

Follow the same procedure for all functions until you reach the last one (St).

5. When St appears on the display, release the button **F** and select:

Y = save the set-up

nO = DO NOT save the set-up

6. Press the **F** button to confirm.

- The display reverts to the automation status view.

■ ADVANCED programming

1. When the display indicates the status of the automation, press and hold down the **F** button, then press the + button as well: the display shows the first function (P1).

Each function will be displayed for as long as button F remains pressed.

2. Release the buttons: the display shows the value of the function.

3. When the display indicates the value of the function, press the + or - button to modify it.

4. Press button **F** to confirm and go to the next function. The modified value becomes effective immediately.

Follow the same procedure for all functions until you reach the last one (St).

5. When St appears on the display, release the button **F** and select:

Y = save the set-up

nO = DO NOT save the set-up



6. Press the **F** button to confirm.

- The display reverts to the automation status view.



NOTE Each modified value is effective immediately, but when you exit from programming mode you must decide whether to save the changes.

UNSAVED changes UNSAVED changes are saved if the power supply is interrupted while programming is being carried out or after 10 minutes if no buttons are pressed.



Access BASIC programming






Access ADVANCED programming




Modify a setting



End of programming (St)



Go immediately to St:



6 BASIC Programming

BASIC Function	Default
]{ Simply Connect If you wish to enable Simply Connect, select a channel (CH). ☐ = Simply Connect NON enabled, 1 = CH 1, 2 = CH 2, 3 = CH 3, 4 = CH 4	0
CF Automation model Set the model installed. Note: whenever the parameter CF is modified, the relative DEFAULT 1 values are loaded on parameter dF. ☐ = no selection (factory default) 3 = RKE 1400 (for SLIDING FHE) 1 = A1000 4 = SF1400 2 = A1400 AIR 5 = GBF1500	☐
dF DEFAULT configuration Allows the default programming specific for the Model of the automation to be loaded. It also indicates whether the programming corresponds with the default parameters. 1 = DEFAULT 1 - standard configuration - Note: whenever parameter CF is modified, the relative DEFAULT 1 values are loaded. 2 = DEFAULT 2 - battery-powered standard configuration, with pre-set tests. The BATTERY KIT must be connected. ☐ = the programming in progress does not correspond to a DEFAULT configuration (at least 1 parameter modified). Select the corresponding value if you wish to reload a DEFAULT program.	4
L☐ Leaf number - displayed only for SF1400 (CF = 4) If modified you have to perform the SETUP. 1 = 1 leaf, 2 = 2 leaves	2
L☒ Select passage opening - displayed only for SF1400 (CF = 4) 1 = narrow opening width: max 65 cm (with 1 leaf), max 130 cm (with 2 leaves) 2 = average opening width: 65...75 cm (with 1 leaf), 130...150 cm (with 2 leaves) 3 = wide opening width: greater than 75 cm (with 1 leaf), greater than 150 cm (with 2 leaves)	2
r☐ Direction of rotation of the motor If it is modified you have to perform the SETUP. 1 = STANDARD rotation, -1 = NON STANDARD rotation	1
PO Partial Open - NOT displayed for SF1400 (CF = 4) or for GBF1500 (CF = 5) ☐ = 100% 20...95 % Adjustment step = 5%	50
PR Pause time before closing again in automatic operation mode 0...30 s Adjustment step = 1 s	2
ES Energy Saving ☐ = not enabled , 4 = enabled	☐
P☐ Night pause time In Night mode, after being opened via the Key command, the door remains open for the length of time set (☐ s ... 4,0 min) 0...58 s Adjustment step = 2 s 1,0...4,0 min Adjustment step = 10 s (e.g. 1,2 = 1 min and 20 s)	10
cS Closing speed level 1...10	5 1 (if cF=4)
oS Opening speed level 1...10	10 (if cF=1) 8 (if cF=2,3) 5 (if cF=4) 3 (if cF=5)
cF Closing force level 1...10	5
oF Opening force level 1...10	8 10 (if cF=3) 5 (if cF=5)
EF Force time on obstacle for CF and OF 0,1...3,0 s Adjustment step = 0,1 s	1,0 2,0 (if cF=3)
dF Deceleration ramp when OP and CL level 1...10	6 4 (if cF=4) 5 (if cF=5)
AF Acceleration ramp when OP and CL level 1...10	8 5 (if cF=3,5)

BASIC Function		Default
Ⓛ1	INPUT I1 (J21) configuration The contact logic can be programmed from the SDK EVO (section § Configurable inputs). ⓃⓃ = input not enabled 1 = External Opening (NO) 4 = Internal Opening (NO) 7 = Automatic Opening (NO) 8 = Semi-Automatic Opening (NO) 9 = Pharmacy Open (NOT for SF1400 and GBF1500) (NO) 10 = KEY (NO) 11 = Partial Open (NOT for SF1400 and GBF1500) (NO) 20 = Closing Safety (NC) 21 = Opening Safety (NC) 23 = Safety STOP (NC) 24 = Closing Safety EXT (NC) 25 = Closing Safety INT (NC) 30 = Emergency Opening (NC) 31 = Emergency Opening with memory (NC) 32 = Emergency STOP (NC) 33 = Emergency STOP with memory (NC) 34 = Emergency Closing (NC) 35 = Emergency Closing with memory (NC) 37 = Emergency Break OUT for APN (NC) 40 = operating mode OPEN (NO) 41 = operating mode EXIT ONLY (NO) 42 = operating mode ENTRY ONLY (NO) 43 = operating mode NIGHT-TIME (NO) 44 = operating mode MANUAL (NO) 45 = operating mode PARTIAL (NOT for SF1400 and GBF1500) (NO) 46 = operating mode INTERLOCK (NO) 47 = operating mode AUTO MANUAL (NO) 60 = TIMER 61 = RESET	1
1F	INPUT I1 TEST Displayed only if the input is configured as Safety (Ⓛ1 = 20 or 21 or 23 or 24 or 25) 4 = TEST enabled , ⓃⓃ = TEST not enabled	ⓃⓃ
Ⓛ2	INPUT I2 (J21) configuration (see options Ⓛ1)	4
2F	INPUT I2 TEST Displayed only if the input is configured as Safety (Ⓛ2 = 20 or 21 or 23 or 24 or 25) 4 = TEST enabled , ⓃⓃ = TEST not enabled	ⓃⓃ
Ⓛ3	INPUT I3 (J21) configuration (see options Ⓛ1)	10
3F	INPUT I3 TEST Displayed only if the input is configured as Safety (Ⓛ3 = 20 or 21 or 23 or 24 or 25) 4 = TEST enabled , ⓃⓃ = TEST not enabled	ⓃⓃ
Ⓛ4	INPUT I4 (J21) configuration (see options Ⓛ1)	7
4F	INPUT I4 TEST Displayed only if the input is configured as Safety (Ⓛ4 = 20 or 21 or 23 or 24 or 25) 4 = TEST enabled , ⓃⓃ = TEST not enabled	ⓃⓃ
PF	PARTIAL PHARMACY - NOT displayed for SF1400 (ⓁF = 4) or for GBF1500 (ⓁF = 5) - Displayed if a configurable input is pharmacy OPEN. 5...95 % Adjustment step = 5%	20
5E	Exit PROGRAMMING Allows you exit from programming and decide whether to save the changes. 4 = save , ⓃⓃ = do not save Press the F button to confirm. After exit, the display shows automation status: 00 CLOSED 01 OPENING 02 OPEN 03 in PAUSE 04 in NIGHT PAUSE 05 CLOSING 06 OPEN or STOPPED or CLOSED in EMERGENCY 07 in MANUAL operating mode 08 in NIGHT-TIME operating mode 10 System TEST in progress 11 STOPPED 12 safeties TEST in progress 13 Door ERROR (Press + and - simultaneously to display the active ERROR) L0-L2 SETUP in progress - phases L0, L1, L2 . in SLEEP mode (flashing dot)	4

7 ADVANCED programming


ADVANCED Function	Default
P1 INPUT S1 (J1) configuration (see options C1)	24
IF INPUT S1 TEST Displayed only if the input is configured as safety (P1 = 20 or 21 or 23 or 24 or 25) 3 = TEST enabled , 0 = TEST not enabled	4
P2 INPUT S2 (J4) configuration (see options C1)	25
2F INPUT S2 TEST Displayed only if the input is configured as Safety (P2 = 20 or 21 or 23 or 24 or 25) 3 = TEST enabled , 0 = TEST not enabled	4
0E OPERATION OF SAFETIES IN OPENING 1 = STOP (stops the opening) , 2 = Low Energy (slow movement)	2
bP BUTTON PHOTOCELLS The TEST is NOT available for these photocells. 0 = no photocell , 1 = 1 pair of photocells , 2 = 2 pairs of photocells	00
E1 INPUT E1 (J7) configuration (see options C1)	00
IF INPUT E1 TEST Displayed only if the input is configured as Safety (E1 = 20 or 21 or 23 or 24 or 25). 3 = TEST enabled , 0 = TEST not enabled	00
E2 INPUT E2 (J7) configuration (see options C1)	00
2F INPUT E2 TEST Displayed only if the input is configured as Safety (E2 = 20 or 21 or 23 or 24 or 25) 3 = TEST enabled , 0 = TEST not enabled	00
bA BATTERY KIT Operation of the emergency battery NOT in NIGHT-TIME mode. 0 = not enabled 1 = OPENS immediately 2 = CLOSES immediately 3 = with flat battery last movement OPENING 4 = with discharged battery last movement CLOSING	00 (if dF=1) 4 (if dF=2)
bN NIGHT BATTERY KIT Operation of the emergency battery in NIGHT-TIME operating mode. Displayed only if the Battery Kit is enabled (bA other than 00). (see options bA)	4
bL OPENING DUE TO LOW BATTERY Displayed only if the Battery Kit is enabled (bA different from 00). The door opens automatically if the battery is discharged, even if there is mains power. 3 = enabled, 0 = not enabled	00 (if dF=1) 4 (if dF=2)
bE BATTERY TEST Displayed only if (bL = 3). Enables the test via a battery powered door opening.	00 (if dF=1) 4 (if dF=2)
E L MOTOR BLOCK XB LOCK / XM LOCK XM LOCK options not displayed for A1000 (CF = 1) 0 = not enabled 1 = XB LOCK closed in NIGHT-TIME mode 2 = XB LOCK closed in ENTRY ONLY, EXIT ONLY, NIGHT-TIME mode 3 = XB LOCK closed in NIGHT-TIME mode and with leaves open 4 = XB LOCK closed in NIGHT-TIME mode and with leaves closed 5 = XB LOCK closed at the end of each movement 6 = XM LOCK closed in NIGHT-TIME mode 7 = XM LOCK closed in ENTRY ONLY, EXIT ONLY, NIGHT-TIME mode 8 = XM LOCK closed in NIGHT-TIME mode and with leaves open 9 = XM LOCK closed in NIGHT-TIME mode and with leaves closed 10 = XM LOCK closed at the end of each movement	00
SU MONITORING of XB LOCK / XM LOCK 0 = not enabled , 4 = enabled	00
dN DOUBLE MOTOR KIT ACTIVATION - NOT displayed for A1000 (CF = 1) or for GBF1500 (CF = 5) 0 = second motor kit not enabled 4 = second motor kit enabled	00
nd NIGHT-TIME MODE DELAY (0 s ... 4.0 min) 0 = not enabled 0 ... 59 s Adjustment step = 1 s 1.0 ... 4.0 min Adjustment step = 10 s (e.g. 1.2 = 1 min and 20 s)	10

ADVANCED Function		Default
<p>01 OUTPUT OUT1 configuration (J22)</p> <p> 00 = not enabled 1 = GONG (NO) 2 = BOARD ERROR/FAULT (NO) 3 = battery operation (NO) 4 = EMERGENCY active (NO) 5 = SAFETIES TEST configured on 11, 12, 13, 14 (NC) 6 = DOOR NOT CLOSED (NO) 7 = DOOR OPEN (NO) 8 = DOOR MOVING (NO) 9 = LIGHT (NO) 10 = INTRUSION ACTIVE (NO) 11 = CLOSING SAFETY (NO) </p>	<p> 12 = SAFETIES (NO) 13 = AIRSLIDE SP1 (NO) 14 = AIRSLIDE SP2 (NO) 15 = LOCK (NO) 16 = PROGRAMMING Simply Connect in PROGRESS 17 = TIMER active 18 = PEOPLE IN NUMBER (NO) 19 = TRAFFIC LIGHT EXT (NO) 20 = TRAFFIC LIGHT INT (NO) 23 = LOW BATTERY 24 = NIGHT </p>	6
02 OUTPUT OUT2 configuration (J22) (see options 01)		2
1n Inputs status The segments of the display corresponding to the input that is active light up		(see the figure)
<p>5t Exit PROGRAMMING Allows you exit from programming and decide whether to save the changes.</p> <p> 4 = save , 00 = do not save Press the F button to confirm. After exit, the display shows automation status (See 5T in Basic programming) </p>		4

INPUTS status

Shown on the Advanced Programming display, function **1n**

segment lit = input active
 The central dot is always lit
 (OFF = segment always off)



7.5 MOVEMENT PARAMETERS

The movement parameters can be adjusted via the programming function.

- **from board** Basic programming:
 - cS = closing speed (level 1...10)
 - oS = opening speed (level 1...10)
 - cF = closing force (level 1...10)
 - oF = opening force (level 1...10)
 - tF = MAX push time on obstacle during closing and opening (0.1 s ... 3 s)
 - dF = opening and closing deceleration ramp (level 1...10)
 - Ar = opening and closing acceleration ramp (level 1...10)
- from **SDK EVO** (allows further adjustments to be made):
 - ↗/PROGRAMMING/MOTION...

```
...OPENING
  SPEED (level 1...10)
  SLOWDOWN deceleration space at end of travel (0...200 cm)
  SLOWDOWN SPEED Deceleration speed at end of travel (level 1...3)
  STRENGTH (level 1...10)
  STRENGTH DURATION (0.1 ... 3.0 s)
  ACCELERATION (level 1...10)
  DECELERATION (level 1...10)
...CLOSING (same options as for OPENING)
...BRAKING Deceleration for reverse movement
(level 1...5)
...STOP MOV Moves the stop position forwards with respect to the opening stop
(level 1...10) 0 = minimum distance
```

7.6 OBSTACLE DETECTION

The sensitivity of the obstacle detection system is adjusted by setting the opening force, closing force and the maximum push time (S Movement parameters). When an obstacle causes the movement to stop, the automation exerts the set static force on the obstacle. Once the set force time on the obstacle has elapsed, if it still cannot move, the programmed operation is activated:

Obstacle during closing If an obstacle is detected during CLOSING it causes the leaves to reverse and subsequently they attempt to close.

Obstacle during opening If an obstacle is detected during OPENING it causes the movement to stop and after 5 s attempts to attempt opening again.

Obstacle during opening in NIGHT-TIME mode If an obstacle is detected during opening it causes the leaves to reverse.

Number of consecutive obstacle detections The count of the number of consecutive obstacle detections can only be enabled via the SDK EVO. The automation stops when the count exceeds the set number (error 24: obstacles during CLOSING or error 31: obstacles during OPENING).

- from **SDK EVO**: ↗/PROGRAMMING/MISCELLANEOUS/CONSECUTIVE OBST.
- ...CLOSING DISABLED (=25 detections) or 1...10 detections
- ...OPENING (as above)

7.7 LOW ENERGY

As a guideline only, in order to protect against risks related to moving parts, the standard EN 16005:2012 requires that the opening and closing movement must take place in Low Energy mode, which means that the kinetic energy of the leaf must not exceed 1.69 joule and the maximum static force must not exceed 67 N.

Alternatively, for doors that open onto heavy traffic areas or when any contact with the user is unacceptable because many of the users are elderly, sick, disabled or children, additional protective devices are to be used.

Among the possible solutions provided, the installation of ESPE equipment compliant with EN 12978 CAT.2 (per EN 954-1 and / or EN 13849) is recommended, to monitor the full width of the door in

both directions of movement.

To set up the Low Energy, mode, program the values for force and kinetic energy by applying standard EN 16005:2012.

- **from board** Basic programming:
 - cS and oS = speed established by applying the standard
 - cF, oF and Ar = 1
- from **SDK EVO**:
 - ↗/PROGRAMMING/MOTION...
- ...OPENING
 - SPEED = speed established by applying the standard
 - STRENGTH = 1
 - ACCELERATION = 1
- ...CLOSING (as above)

7.8 INTRUSION: KEEP CLOSED/PULL&GO

When the automation is closed, the board detects if there is an attempt to open it manually (INTRUSION). The response to this can be defined via the SDK EVO: KEEP CLOSED or PULL & GO.

- from **SDK EVO**: ↗/PROGRAMMING/MISCELLANEOUS/INTRUSION ...
- ...KEEP CLOSED
 - STRENGTH KEEP CLOSED (level 1...10)

Or

...PULL & GO

KEEP CLOSED The motor starts, counteracts the manual opening with an adjustable force and keeps the automation CLOSED. **Note:** in NIGHT-TIME operating mode with battery operation, KEEP CLOSED is not active.

PULL & GO The motor starts up to complete the opening. **Note:** in NIGHT-TIME operating mode with battery operation, PULL & GO is not active.

7.9 ENERGY SAVING

Energy Saving allows you to decrease the opening/closing times and to limit the number of "false openings" by recognising the pedestrian's transit direction (approaching, leaving, cross traffic). Opening is via external or internal radar. When radars and presence sensors are disengaged, it closes immediately, even if the opening movement has not been completed. It also closes immediately when an input configured as Closing safety is deactivated.

Obligatory requirements:

- mode of operation AUTOMATIC TWO-DIRECTIONAL
- use of the one-direction radar detectors (Energy Saving is active only on INTERNAL OPENING and EXTERNAL OPENING inputs)

Programming:

- **from board** Basic programming: ES = 3
- from **SDK EVO**: ↗/PROGRAMMING/Energy Saving ENABLED

7.10 TIMING AND PARTIAL OPENING

The following can be programmed:

PAUSE TIME

- **from Board** Basic Programming: P_H
- from **SDK EVO**: ↗/PROGRAMMING/TIMING/PAUSE TIME

NIGHT PAUSE TIME

- **from Board** Basic Programming: P_N
- from **SDK EVO**: ↗/PROGRAMMING/TIMING/NIGHT PAUSE TIME

PARTIAL OPEN (NOT for SF1400 and GBF1500)

- **from Board** Basic Programming: P_O Adjustment step 5%.
- from **SDK EVO**: ↗/PROGRAMMING/MISCELLANEOUS/PARTIAL OPEN Adjustment step 1%.

Then select how partial open is carried out:

STANDARD partial open is fixed at the set percentage

100% INT+EXT partial open increases automatically to 100% if the internal and external sensors are engaged at the same time (it reverts to the set percentage when

at least one sensor is released).

PARTIAL PHARMACY

- from Board Advanced Programming: PF
- from SDK EVO: /PROGRAMMING/MISCELLANEOUS/PARTIAL PHARMACY

NIGHT-TIME MODE DELAY

- from Board Advanced Programming: nD
- from SDK EVO: /PROGRAMMING/TIMING/NIGHT SENSOR DELAY

7.11 DATE AND TIME

- from SDK EVO: /PROGRAMMING/DATE/TIME...
- ...SET DATE DD:MM
- ...SET TIME HH:mm

7.12 COUNTERS

CYCLE COUNTER - SCHEDULED MAINTENANCE

The SDK EVO can be used to enable the cycle counter and issue a maintenance request according to the number of cycles carried out or on a set date.

- from SDK EVO: /COUNTERS/CYCLES COUNT...

...CYCLES NUMBER displays the number of cycles carried out, divided into ABSOLUTE (NOT resettable) and RELATIVE cycles.

...MAINTENANCE enter the TECHNICIAN PSW and confirm.

go to MAINTENANCE CYCLES select: DISABLED or ENABLED and specify the number of cycles for maintenance (step 10000, maximum 1000000) and confirm.

go to MAINTENANCE DATE select: DISABLED or ENABLED and set the date: 00/00/00

If both options are enabled, a maintenance request is issued when the first event is reached (CYCLES or DATE).

...CYCLES RESET (TECHNICIAN PSW required) To reset the RELATIVE cycles counter, confirm with OK. The ABSOLUTE cycles counter can only be reset using the Restoring Factory Defaults procedure (§ relative sections).

SAFE FLOW

This function counts the people entering/leaving the premises for capacity and queue management.

SDK EVO allows you to enable the function and to set the maximum number of people allowed in. The count is displayed in relation to the maximum programmed number in place of the date on the HOME PAGE of the SDK EVO.

The count is carried out in AUTOMATIC and DOOR OPENED mode and is zeroed when the door is put into MANUAL or NIGHT mode.

- from SDK EVO: /COUNTERS /SAFE FLOW...

...FUNCTION select:

DISABLED = SAFE FLOW disabled

PEOPLE IN AUTO = enables counting and alarm. Alarm (40) is triggered when the maximum number of people allowed is reached.

PEOPLE IN EXIT ONLY = enables counting and alarm. Alarm (40) is triggered when the maximum number of people allowed is reached and the door does not allow people to enter until the number of people in the premises falls below the set threshold.

...PEOPLE IN NUMBER sets the number of people allowed in (1...1000)

...PEOPLE IN UPDATE it allows the number of people in the premises (0...1000) to be corrected manually if necessary

NOTE: In an INTERCOM network (see Section § INTERCOM) the SAFE FLOW (PEOPLE IN NUMBER, PEOPLE IN UPDATEFUNCTION) has to be programmed on the MASTER unit. Then SAFE FLOW can also be enabled on the individual SLAVE boards via the PEOPLE IN SLAVE parameter, displayed only on the SLAVE boards.



For the connections, configurations and devices required, see the SAFE FLOW instructions.

7.13 TIMER

The TIMER function allows the operating mode of the automation to be activated for programmed time bands. The operating mode activated automatically by the TIMER cannot be changed manually, unless you disable the TIMER.

Programming is carried out via the SDK EVO, it requires a clock battery to be installed on board E1SL (2) and the date and time to be set correctly.

Programming can be done by day of the week (WEEKLY) and/or by calendar date (JOLLY), e.g: for holidays, company closure... If both have been programmed, in the event of an overlap, the JOLLY has priority.

A TIME BAND is programmed with:

- START time - END time (HH:mm)
- Operating mode

TIMER operating mode

0	NO FUNCTION
1	AUTO BIDIR (auto bidir total)
2	AUTO OUT (automatic exit only total)
3	AUTO BIDIR PARTIAL
4	AUTO OUT PARTIAL (automatic exit only partial)
5	TOTALLY OPEN
6	PARTIAL OPEN
7	AUTO IN (automatic entry only total)
8	AUTO IN PARTIAL (automatic entry only partial)
9	NIGHT (night total)
10	PARTIAL NIGHT
11	INTERLOCK (INTERLOCK bidirectional total)
12	INTERLOCK OUT (INTERLOCK exit only total)
13	INTERLOCK IN (INTERLOCK entry only total)
14	AUTO MANUAL (auto manual total)

1 or more TIME BANDS can be programmed (max 6) in 24 h.

When it exits from a programmed TIME BAND, if there is no subsequent time band, the automation goes into AUTOMATIC TWO-DIRECTIONAL TOTAL mode. Outside of the programmed time bands, the Operating mode can be changed manually (from a Configured input or Function selector).

WEEKLY PROGRAMMING

Program the required days with the required time bands. To quickly program one or more time bands for a group of days, program the group MON - SUN or MON - FRI. Next, each time band can be reprogrammed for a single day.

/TIMER...

... MONDAY... SUNDAY/MON-SUN/MON-FRI Select the day or group of days

... SLOT1... SLOT6 Select the time band

... FUNCTION: 0...14 Assign the operating mode from the TIMER

... BEGINNING 00:00 Set the TIME SLOT start time.

... END 00:00 Set the TIME SLOT end time.

If you are programming a group of days, after entering the END time of the time band, the following question appears:

... DO YOU WANT TO APPLY MON - FRI? OK

Carry out the same procedure for any other time bands. DO NOT program overlapping time bands. Complete the weekly programming for all the required days.

JOLLY PROGRAMMING

Program the JOLLY time bands. The JOLLY programming must be applied to the dates specified in JOLLY SLOTS.

A JOLLY SLOT is defined by the START and END date of the slot. A maximum of 12 JOLLY SLOTS can be programmed. A slot consisting of one day has the same start and end date. A slot consisting of several days cannot extend beyond December 31st. E.g. the period from December 25th to January 6th is covered by two slots: 25...31/12 + 01...06/01.

/TIMER...

...JOLLY
 ...SLOT1...SLOT6 Select the time band
 ...FUNCTION: 0...14 Assign the operating mode from the TIMER
 ...BEGINNING 00:00 Set the start time of the TIME BAND
 ...END 00:00 Set the end time of the TIME BAND

Carry out the same procedure for any other time bands. **DO NOT** program JOLLY time bands that overlap.

...JOLLY SLOTS... Select the SLOT

Select **DISABLED** if you wish to delete the slot. Select **ENABLED** to specify the dates for the slot:

...BEGINNING 00:00 day:month
 ...END 00:00 day:month

■ **EXAMPLE Programming the TIMER for a shop open from Monday to Saturday between the hours of 08:00 and 13:00 and 15:00 to 19:30. Closed on: Thursday Closed for holidays from 1st to 15th August.**

Program the weekly TIMER :

🔧 /TIMER...

... MON - SUN

SLOT 1 / FUNCTION: 1 / BEGINNING 08:00 / END 12:59

SLOT 2 / FUNCTION: 9 / BEGINNING 13:00 / END 14:59

When the automation exits from TIME BAND 2 it goes into **AUTOMATIC TWO DIRECTIONAL TOTAL** mode and the mode can be changed from a configured input or from a function selector.

SLOT 3 / FUNCTION: 4 / BEGINNING 19:30 / END 19:44

SLOT 4 / FUNCTION: 9 / BEGINNING 19:45 / END 23:59

SLOT 5 / FUNCTION: 9 / BEGINNING 00:00 / END 07:59

Apply **MON - SUN**, then reprogram **THURSDAY** and **SUNDAY** (deleting the bands that are not used):

... THURSDAY / SLOT1 / FUNCTION: 9 / BEGINNING 00:00 / END 23:59

... SUNDAY / SLOT1 / FUNCTION: 9 / BEGINNING 00:00 / END 23:59

Program the holiday closure:

... JOLLY

SLOT1 / FUNCTION: 9 / BEGINNING 00:00 / END 23:59

... JOLLY SLOTS

SLOT 1 / ENABLED / BEGINNING 01:08 / END 15:08

ENABLING/DISABLING THE TIMER

Enable the **TIMER** in order to use the programmed time bands. Use the input configured as **TIMER**, if present on the board. If there is **NO** input configured as **TIMER**, the **SDK EVO** can be used.

🔧 /TIMER/1 TIMER STATE select **ENABLED/DISABLED**

- When **TIMER** is enabled, **T** is indicated on the **HOME PAGE** of the **SDK EVO**.

- The time bands are remembered even if the **TIMER** is disabled.

8. ACCESSORIES

EMERGENCY BATTERY

The battery kit allows the automation to operate in case of mains power failure.

To conserve battery power, the board activates the **LOW POWER** mode: it turns off power to the accessories apart from the **SDK EVO** (to which it disables the backlighting), it **DOES NOT** carry out the **PULL & GO** function, if enabled. The board maintains the battery charge, but does not charge batteries that are completely discharged.

1. Connect the emergency battery kit.



Emergency battery connection

J14

2. Enable the battery specifying the operation to be carried out when there is no mains power: the movement is carried out **IMMEDIATELY** or when the charge level drops (**LAST MOVEMENT**), then the operation stops until the mains power is restored. To enable the battery in **NIGHT** mode, the operations are similar. It is possible to program immediate opening each time the battery becomes discharged, even if there is mains power. If this option is enabled, the battery opening charge **TEST** is available. If the charge is too low, the door remains open until it has been restored. The test (with the door in status 10) is carried out even if there is mains power every 24 hours, every time the door is turned on, after a **RESET** and when exiting from **MODFUN NIGHT**, **MANUAL**, **AUTO_MANUAL**. It is not active in **MODFUN NIGHT**, **OPENED**, **MANUAL**, **AUTO_MANUAL** and in **INTERLOCK**.

- from Board, Advanced Programming:

bR in all Operating Modes apart from **NIGHT-TIME**

n0 = not enabled

1 = OPENS IMMEDIATELY

2 = CLOSES IMMEDIATELY

3 = LAST MOVEMENT OPENING

4 = LAST MOVEMENT CLOSING

bR in **NIGHT-TIME** mode (see options **bR**)

bL OPENING DUE TO LOW BATTERY (NOT in **NIGHT** mode) **Y** = enabled, **n0** = disabled

bE BATTERY CHARGE TEST **Y** = enabled, **n0** = disabled

- from **SDK EVO**:

🔧 /PROGRAMMING/BATTERY KIT...

...FUNCTION: **DISABLED**, UNTIL LAST MOVEMENT, LAST MOVEMENT ONLY

...LAST MOVEMENT: **OPENING**, **CLOSING**

NIGHT MODE: **LAST MOVEMENT ONLY**, UNTIL LAST MOVEMENT

...LAST MOVEMENT **NIGHT**: **OPENING**, **CLOSING**

...OPENING **LOW BATT.**: choose: **ENABLED** or **DISABLED**

...OPENING **TEST**: choose: **ENABLED** or **DISABLED**



The **DEFAULT 2** configuration enables battery battery-powered standard configuration, with pre-set tests:

- if there is a mains power failure, the battery immediately carries out an **OPENING** movement and then stops until the mains power has been restored

- when the battery is discharged, the door **OPENS** immediately (it closes if in **NIGHT** mode) and output **OUT2** indicates **LOW BATTERY**

- the charge **TEST** via battery opening is enabled even if there is mains power and if the charge level is low, the door remains open until it has been restored.

XB LOCK MOTOR BLOCK AND MONITORING (OPTIONAL)

The motor block allows the leaves to be locked mechanically.

The motor block is never engaged in MANUAL mode.

If there is a power failure, the position of the XB LOCK remains unchanged. When the automation is operating on battery, the motor block is only active in NIGHT mode (operation can only be modified via the SDK EVO).



Always turn off the mains power supply and disconnect the emergency battery (if present) before connecting or disconnecting the motor block.

1. Install the motor block following the installation instructions.
2. Connect the motor block to the E1SL board using the connector (A).
3. If installed, connect the monitoring device (B) to the terminal board of the motor block.
4. During programming, assign the motor block function and enable monitoring, if installed.

- from Board, Advanced Programming:

$E_L = 1 \dots 5$; $S_U = 4$ (if monitoring is installed)

or

- from SDK EVO:

/PROGRAMMING/KIT LOCK...

...TYPE XB LOCK

...FUNCTION

...SURVEILLANCE KIT

...BATT. FUNCTION

MOTOR BLOCK FUNCTION:

DISABLED ($E_L = \square$): not active

NIGHT ($E_L = 1$): with the automation in NIGHT mode, locks the closed leaves and the open leaves with the Pharmacy Open command

NIGHT + MONODIR ($E_L = 2$): NIGHT + with the automation in ENTRY ONLY / EXIT ONLY mode, locks the closed leaves

NIGHT + OPENED ($E_L = 3$): NIGHT + with the automation in any mode (apart from MANUAL), always locks the open leaves

NIGHT + CLOSED ($E_L = 4$): NIGHT + with the automation in any mode (apart from MANUAL), always locks the closed leaves

ALWAYS ($E_L = 5$): with the automation in any mode (apart from MANUAL), locks the leaves after any opening / closing movement

Motor block operation when the automation is operating on battery:


- from SDK EVO ... KIT LOCK/ BATT. FUNCTION

NIGHT: active only as NIGHT (DEFAULT)


STANDARD: maintains the programmed function (E_L or ... KIT LOCK/FUNCTION)

ALWAYS OPEN: the automation never locks the leaves irrespective of the mode

XB LOCK and monitoring connection (optional)



1 green	B Motor block monitoring (IF INSTALLED)
2 pink	C Manual release microswitch
3 yellow	
4 white	D Motor block coil (connected at the factory)
5 brown	



10

XM LOCK MOTOR BLOCK AND MONITORING

The motor block allows the leaves to be locked mechanically.

The motor block is never engaged in MANUAL mode.

If there is a power failure, the XM LOCK disengages (unlocks the leaves). When the automation is operating on battery, the motor block is only active in NIGHT mode (operation can only be modified via the SDK EVO).

! Always turn off the mains power supply and disconnect the emergency battery (if present) before connecting or disconnecting the motor block.

1. Install the motor block following the installation instructions.
2. Connect the motor block to the E1SL using the connector (A).
3. If installed, connect the monitoring device (B) to the terminal board of the motor block.
4. During Programming, assign the motor block function and enable monitoring, if installed.

- from Board, Advanced Programming:

E_L = 6...10 ; S_L = 9 (if monitoring is installed)

or

- from SDK EVO:

/PROGRAMMING/KIT LOCK...

...TYPE XM LOCK

...FUNCTION

...SURVEILLANCE KIT

...BATT. FUNCTION

MOTOR BLOCK FUNCTION:

DISABLED (E_L=□): not active

NIGHT (E_L=5): with the automation in NIGHT mode, locks the closed leaves and the open leaves with the Pharmacy Open command

NIGHT + MONODIR (E_L=7): NIGHT + with the automation in ONLY IN / EXIT ONLY mode, locks the closed leaves

NIGHT + OPENED (E_L=8): NIGHT + with the automation in any mode (apart from MANUAL), always locks the open leaves

NIGHT + CLOSED (E_L=9): NIGHT + with the automation in any mode (apart from MANUAL), always locks the closed leaves

ALWAYS (E_L=10): with the automation in any mode (apart from MANUAL), locks the leaves after any opening / closing movement

Motor block operation when the automation is operating on battery:

- from SDK EVO ...KIT LOCK/ BATT. FUNCTION

NIGHT: active only as NIGHT (DEFAULT)

STANDARD: maintains the programmed function (E_L or ...KIT LOCK/FUNCTION)

ALWAYS OPEN: the automation never locks the leaves irrespective of the mode

ELASTIC KIT

(NOT available for SF1400 and GBF1500)

The elastic anti-panic kit XDEK allows the leaves to be opened in the event of a power failure.

1. Install and adjust the XDEK following the instructions.
2. Enable the XDEK and KEEP CLOSED during programming.

Only from the SDK EVO:


/PROGRAMMING/MISCELLANEUS...

... ELASTIC KIT (enabled) OK



... MISCELLANEUS/INTRUSION/KEEP CLOSED OK

... KEEP CLOSED (force KEEP CLOSED 1...10)

XM LOCK and monitoring connection (optional)



1	green	B	Motor block monitoring (if installed)
2	pink		
3	not used	C	Motor block coil (connected at the factory)
4	white		
5	brown		



ENGLISH
Translation of the original instructions

ONE DUAL TECHNOLOGY ENTRY AND EXIT DETECTOR

! It is obligatory to install protective barriers in the movement areas in the event contact with persons is not allowed.

The dual technology detectors allow radar detection to be used for opening and infrared detection to be used for safety. Use the XV1 or XDT1 exit and entry detector in compliance with EN 16005:2012 and DIN18650.


The default programming of the E1SL corresponds to the typical example configuration shown in the figure.

from Board	from SDK EVO
P1=24	INPUTS S1-S2
I F=4	S1 Function = Closing Safety (infrared safety)
P2=25	S1 Test = Enabled
2 F=4	S1 NO/NC = NC
	S2 Function = Closing Safety (infrared safety)
	S2 Test = Enabled
	S2NO/NC = NC
C1=1	INPUTS I1-I2
C2=4	I1 = External sensor contact (radar detection)
	I1 NO/NC = NO
	I2 = Internal sensor contact (radar detection)
	I2 NO/NC = NO


1. With the board switched off, connect the external detector and the internal detector. Follow the colour coding of the wiring shown in the figure.
2. Turn power on to the E1SL board. The detectors turn on.
3. Carry out the SETUP procedure for each detector (see the device instructions).

i It is recommended not to activate the "narrow pavement" function which combines radar and infrared detection for opening.

4. If necessary, program the configurable inputs on the automation board differently.
 - from Board: Basic Programming for the inputs of terminal board J21. Advanced Programming for the inputs of terminal boards J1 and J4.
 - or
 - from SDK EVO: **/PROGRAMMING/INPUTS OUTPUTS...**
 - ...INPUTS I1-I4
 - ...INPUTS S1-S2
 - ...INPUTS E1-E2
5. Check for correct operation.




Example: configuration with dual technology entry and exit detectors. This configuration corresponds to the default programming of the board. XV1 or XDT1 detectors can be used, on both the outside or inside.




12

Dual technology radar/infrared detector connection



EXTERNAL infrared

INTERNAL infrared



13

2 DUAL TECHNOLOGY ENTRY AND EXIT DETECTORS



It is obligatory to install protective barriers in the movement areas in the event contact with persons is not allowed.

The XDT1 dual technology detectors allow radar detection to be used for opening and infrared detection to be used for safety. Install 2 entry and 2 exit radar detectors to cover large accesses, in compliance with EN 16005:2012 and DIN18650.


from Board	from SDK EVO
P1 = 24	S1-S2 safeties
1F = 3	S1 Function = Closing Safety
P2 = 25	S1 Test = Enabled
2F = 4	S1 NO/NC = NC
	S2 Function = Closing Safety
	S2 TEST = Enabled
	S2NO/NC = NC
C1 = 1	INPUTS I1-I2
C2 = 4	I1 = External sensor contact
	I2 = Internal sensor contact
	I1 NO/NC = NO
	I2 NO/NC = NO

1. With the board switched off, connect the external and internal detectors. Follow the colour coding of the wiring shown in the figure.
 - Connect the 2 external infrared detectors and the 2 internal infrared detectors in series (see figure).
2. Turn power on to the automation board. The detectors turn on.
3. Carry out the SETUP procedure for each detector (see the device instructions).




It is recommended not to activate the "narrow pavement" function which combines radar and infrared detection for opening.


4. If necessary, program the configurable inputs on the automation board differently.
 - **from Board:** Basic Programming for the inputs of terminal board J21. Advanced Programming for the inputs of terminal boards J1 and J4.
- or
- **from SDK EVO:**
 - /PROGRAMMING/INPUTS OUTPUTS...
 - ...INPUTS I1-I4
 - ...SAFETIES S1-S2
5. Check for correct operation.




Example: configuration with 2 dual technology detectors at the entrance and 2 at the exit. This configuration corresponds to the default programming of the board.




15



Dual technology radar/infrared detector connection



SERIES connection of 2 external infrared detectors and 2 internal infrared detectors.



14

INFRARED DETECTOR FOR SAFETY IN OPENING



It is obligatory to install protective barriers in the movement areas in the event contact with persons is not allowed.




Use this configuration to protect the opening movement space by means of safety detectors.

The XBFA ON infrared detectors allow safety in opening in compliance with EN 16005:2012 and DIN18650.


The default programming of the E1SL corresponds to the typical example configuration shown in the figure.

from Board	from SDK EVO
o1 = 5	Inputs 01 01 Function = TEST 01 NO/NC = NO (only via the SDK EVO)
C3 = 21 3F = 4	INPUTS I3-I4 I3 = Safety on opening I3 NO/NC = NC I3 TEST = Enabled
C4 = 21 4F = 4	I4 = Safety on opening I4 NO/NC = NC I4 TEST = Enabled



1. With the board switched off, connect the detectors. Follow the colour coding of the wiring shown in the figure.
 2. Turn power on to the E1SL board. The detectors turn on.
 3. Carry out the SETUP procedure for each detector (see the device instructions).
 4. If necessary, program the configurable inputs on the automation board differently.
 - from Board: Basic Programming for the inputs of terminal board J21. Advanced Programming for the inputs of terminal board J22.
- or
- from SDK EVO:
 - ✂ /PROGRAMMING/INPUTS OUTPUTS...
 - ...OUTPUTS 01-02
 - ...INPUTS I1-I4
5. Check for correct operation.



Example: configuration with 2 infrared detectors at the exit.



Infrared technology detectors connection



XFA BUTTON PHOTOCELLS



Photocells are not permitted as safety devices in European Community countries in which the EN 16005:2012 standard is in force. Specifically, photocells are considered as auxiliary devices, complementary to safety.

The button photocells are active during CLOSING.

1. Connect the photocells.

	CABLE colour
TX - transmitter	grey and blue (grey sheath)
RX - receiver	black and blue (black sheath)

Note: leave the inputs of the connector free if button photocells are not used.

2. Enable the photocells.

- from Board: advanced programming

bP = 1 1 pair


bP = 2 2 pairs

or


- from SDK EVO:

/PROGRAMMING/INPUTS OUTPUTS/PHOTOCELLS XFA 1 PAIR or 2 PAIRS

1 Pair of button photocells connection



2 Pairs of button photocells connection



J9

	R2	2nd pair receiver connection
	G	GND Receiver negative
	R1	1st pair receiver connection
	T2	2nd pair transmitter connection
	G	GND Transmitter negative
	T1	1st pair transmitter connection

9. INTERCOM

INTERCOM is the network of connected FAAC automatic doors that can be programmed via SDK EVO or Simply Connect (specific instructions). INTERCOM can control up to 15 boards (called NODES), each of which has a different (ID) number.

INSTALLING INTERCOM

1. Connect all the boards together using 3 wires in a cascade configuration, in any order, to the dedicated connectors. **WARNING:** the JUMPER J26 must ONLY be used on the first and last board of the cascade connection, remove it from intermediate boards (if present).
2. Assign a different ID to each by connecting the SDK EVO in turn to each individual board.
 - **/PROGRAMMING/INTERCOM/ID:** select ID 1...15
3. Specify the network MASTER by assigning it ID = 1. **IMPORTANT** The MASTER board allows network control. The MASTER must be a E1RD board, if that model is used in the network. The other boards are called SLAVE.
4. Register all the boards in the network via the SDK EVO connected to the MASTER board:
 - **/PROGRAMMING/INTERCOM/NODES ENTRY**
 When finished, NODE LIST appears. Make sure that all the boards have been registered.

OPERATING MODE

The operating mode for all the boards in the network is set using the MASTER board:
set the mode on the HOME PAGE of the SDK EVO or via a configured input.

BOARDS IN MAINTENANCE

One or more "SLAVE" boards can be disconnected temporarily from the INTERCOM network mode using the "MASTER" board.

- **/PROGRAMMING/INTERCOM/NODE LIST ...** (select and confirm the ID)
- ... MAINTENANCE for the selected ID choose:
 - LOCAL = (NOT possible for ID=1) the operating mode of the door is independent of the network INTERCOM
 - MANUAL = door in MANUAL mode
 - DISABLED = the door resumes operation in network mode INTERCOM


INTERCOM DIAGNOSTICS

Every board in the network can be checked using the MASTER board.
- **/PROGRAMMING/INTERCOM/NODE LIST** (registered IDs)
Select an ID and press OK to display INFO, ERRORS, WARNINGS, CYCLES NUMBER.
ID...(*) = ID temporarily disconnected from the network
ID...(!) = ID error

INTERLOCK, INTERLEAVES, AIRSLIDE


To configure INTERLOCK, INTERLEAVES, AIRSLIDE, see § Specific sections. You must keep to the pre-set ID associations. An example is shown in [20](#).

Cascade connection. **JUMPER J26: ONLY** on the first and last board of the cascade connection, remove it from intermediate boards (if present).




J18

G	GND Accessories power supply negative and Common contacts
CL	INTERCOM
CH	INTERCOM
G	GND Accessories power supply negative and Common contacts



19

Example of INTERCOM network on 2 accesses (A and B) that both require 2 INTERLEAVES automations. The automations on access B, that faces the outside, are fitted with AIRSLIDE. A and B are interlocked (INTERLOCK mode): one access can open only when the other is closed.



Pre-set ID associations

INTERLOCK		AIRSLIDE	
E1SL	E1SL	E1SL	E1AS (DIP switch)
1	3	1	9
INTERLEAVES		2	10
E1SL	E1SL	3	11
1	2	4	12
3	4	5	13
5	6	6	14
7	8	7	15

20

9.1 INTERLOCK

INTERLOCK allows 2 interlocked accesses to be created: the opening of one access is subject to the closing of the other and vice versa.

- Both accesses must be closed in order for a detector or button to OPEN the access. If this condition is not met, the OPEN command is not executed and an "OPEN-request" is generated. The "OPEN-request" it is carried out as soon as both accesses are closed again.

Use one-direction radar detectors (see relative section).

i INTERLOCK is not available on E1RD boards.

INTERLOCK can be with or without memory:

■ INTERLOCK WITH NO MEMORY

OPEN detectors must be installed both outside and inside each access. The opening is always controlled by the detectors and it is opened only if both accesses are closed.

■ INTERLOCK WITH MEMORY

The detector that opens the first access generates the command to open the second access automatically. This command remains in memory to be carried out after the first access has closed.

Set INTERLOCK with memory when OPEN detectors are NOT installed in the area between the two accesses (even if OPEN BUTTONS are installed to prevent entrapment).

INSTALLING INTERLOCK

INTERLOCK can only be programmed between nodes ID1 and ID3.

1. With both boards switched off, connect the boards together (connectors J18) via 3 wires in a cascade configuration, then turn power on to the boards.
2. Connect the SDK EVO to the first board, assign the ID, then enable INTERLOCK.
 - **/PROGRAMMING/INTERCOM...**
 - ...ID = 1 (MASTER)
 - ...INTERLOCK WITH MEMORY or NO MEMORY (associated ID)
3. Connect the SDK EVO to the second board and carry out the operations as in step 2, assigning ID 3.

Program any other NODES in INTERCOM.


4. Register all the network IDs using the MASTER:
 - **/PROGRAMMING/INTERCOM/NODES ENTRY**
 When finished, NODE LIST appears. Make sure that all the nodes have been registered.
5. Press ESC repeatedly until you return to the main menu.

ENABLING / DISABLING INTERLOCK

Activate the appropriate input command configured on the MASTER, or via the SDK EVO connected to the MASTER:

→/MODFUN press **↔** or **||** until **☐** (INTERLOCK active) appears.


INTERLOCK WITH NO MEMORY: OPEN SENSORS inside and outside on access A and also on access B.



	S1	S2	S3	S4
accesses A and B closed	opens A	opens A	opens B	opens B
access A not closed	opens A	opens A	OPEN B requested	OPEN B requested
access A closed	OPEN A requested	OPEN A requested	opens B	opens B
access B not closed			opens B	opens B

S1,S2,S3,S4 one-direction radar detectors

INTERLOCK WITH MEMORY: access A with an OPEN SENSOR on the outside, access B with an OPEN SENSOR on the inside.



☐A, **☐B** OPEN button access A, access B

	S1	S4	pA	pB
accesses A and B closed	opens A then B*	opens B then A*	opens A	opens B
access A not closed	opens A then B*	OPEN-requested	----	----
access B closed		B then A*		
access A closed	OPEN-requested	opens B then A*	----	----
access B not closed	A then B*			

* automatic opening after the first access has closed

S1,S4 one-direction radar detectors

9.2 AIRSLIDE

An AIRSLIDE device can be installed that is controlled by the automation via the INTERCOM network. AIRSLIDE is activated when the door is opening or closing, or open (status other than "closed") and deactivates when the door is closed. The fan speed can be automatically decreased when people are detected (via safety detectors) in the access.

INSTALLING AIRSLIDE


1. Install the AIRSLIDE device following the instructions provided. On the E1AS board:
 - assign ID=9 using the DIP switch SW4
 - place a jumper between inputs 1 and 3 and the negative (6) on terminal board J1
 2. With the mains power supply switched off and the emergency battery disconnected, make the network connection between the boards.
 3. Turn power on to the boards.
 4. With the SDK EVO connected to the E1SL, assign ID 1 to E1SL and then enable AIRSLIDE:
 - `/PROGRAMMING/INTERCOM/ID:`
 - ... INTERCOM ID ID = 1
 - ... AIRSLIDE ENABLED (ID = 9)
 5. Register the boards on the network (each board is called a NODE).
 - ... NODES ENTRY
 - ... ARE YOU SURE? OK ... WAIT ... NODE LIST
 6. Enable the function and program the speed of the fan:
 - ... NODE LIST select the ID AIRSLIDE and OK
 - ... FUNCTION select ENABLED and OK
 - ... SPEED1 1...4 adjusts the normal speed (e.g. = 3) and OK
 - ... SPEED2 1...4 adjusts the reduced speed (e.g. = 1) and OK
- If you do not require a variable speed**, assign the same value to both.
7. Lastly, press ESC repeatedly until you return to the main menu of SDK EVO.

The NODE LIST menu displays a menu for each board connected to the network.

- `/PROGRAMMING/INTERCOM/NODE LIST` press OK
- note:** ID indicated with (*) = NOT on network, ID indicated with (!) = error
- NODE LIST select an ID and press OK to display the menu
- ... ID = 1 (A1400 AIR) and OK displays:
- INFO (FWversion) ...ERRORS ...WARNINGS ...CYCLES NUMBER ...MAINTENANCE allows the door to be placed in manual mode (select MANUAL) or restore operation (select DISABLED)
- ... ID = 9 (AIRSLIDE) and OK displays:
- INFO (FWversion) ...FUNCTION (ENABLED = on network / DISABLED NON on network) ...SPEED1 (adjustable) ...SPEED2 (adjustable)

To install additional AIRSLIDE, proceed in the same way keeping to the pre-set ID associations.

Automation with AIRSLIDE




E1SL	E1AS (DIP switch)
1	9
2	10
3	11
4	12
5	13
6	14
7	15
8	

E1AS (AIRSLIDE)


DIP switch SW4: ID=9



Terminal board J1: place a jumper between inputs 1 and 3 and the negative.




Network connection between boards E1SL (J18) / E1AS (J2)



J18

	G GND Accessories power supply negative and Common contacts
	CL INTERCOM
	CH INTERCOM
	G GND Accessories power supply negative and Common contacts



9.3 INTERLEAVES

INTERLEAVES allows pairs of automations that work simultaneously to cover an access (simultaneous opening/closing) to be created.

PULL & GO If activated on both boards, it has an effect on both and opens both leaves.

Obstacle has an effect on both. If an obstacle is detected on a closing leaf, both leaves reopen.

RESET is carried out on both boards.

OPEN and SAFETY inputs The OPEN and SAFETY inputs (from 1 to 29) are transmitted from one board to the other and have a simultaneous effect on the pair of INTERLEAVES. E.g. EMERG OPEN connected to ID1 for the simultaneous emergency opening of ID1 and ID2. If connected to even numbered IDs, the EMERG inputs only activate the board that is connected. E.g. EMERG OPEN connected to ID2 for the emergency opening of ID2 only.

EMERGENCY inputs The EMERG inputs (from 30 to 39) must be connected to an odd numbered ID if you want them to have simultaneous effect on the pair of INTERLEAVES. E.g. EMERG OPEN connected to ID1 for the simultaneous emergency opening of ID1 and ID2. If connected to even numbered IDs, the EMERG inputs only activate the board that is connected. E.g. EMERG OPEN connected to ID2 for the emergency opening of ID2 only.


MODFUN input The MODFUN is set on the MASTER (ID1).

TIMER input The TIMER is set on the MASTER (ID1).

INSTALLING INTERLEAVES

1. With both boards switched off, connect the boards together (connectors J18) via 3 wires in a cascade configuration, then turn power on to the boards.
2. Connect the SDK EVO to the first board, assign the ID, then enable INTERLEAVES:
 - /PROGRAMMING/INTERCOM...
 - ...ID pre-set IDs (23)
 - ...INTERLEAVES select ENABLED (associated INTERLEAVES ID)
3. Connect the SDK EVO to the second board and carry out the operations as in step 2, assigning the associated INTERLEAVES ID. Program any other NODES in INTERCOM.
4. Register all the network IDs using the MASTER:
 - /PROGRAMMING/INTERCOM/NODES ENTRY
 When finished, NODE LIST appears. Make sure that all the nodes have been registered.
5. Press ESC repeatedly until you return to the main menu.

Example of 2 automations in INTERLEAVES mode covering one access.



Pre-set IDs for INTERLEAVES:

E1SL	E1SL
Associated INTERLEAVES ID	
1	2
3	4
5	6
7	8

With SDK EVO connected to the first E1SL:

- /PROGRAMMING/INTERCOM...
- ...ID 1
- ...INTERLEAVES ENABLED (ID = 2)

With SDK EVO connected to the second E1SL:

- /PROGRAMMING/INTERCOM...
- ...ID 2
- ...INTERLEAVES ENABLED (ID = 1)

23

10. FW UPDATES AND FILE DOWNLOAD - USB

FAAC provides updated firmware in a package called ZIPACK, which contains the files in versions that are compatible with one another. In order to be used, the files must be saved to the root directory of a USB storage device (not in a folder or zip file and without the original names being changed).

i Use a USB memory device that has a maximum power consumption of 500 mA and formatted with the FAT or FAT 32 file system. The NTFS format is not recognised by the board.

AUTOUPDATE

This procedure is available starting from Bootloader version 3.0.

For boards with previous versions, carry out the manual update procedure from the Upload / Download Menu.

1. With the board switched on, insert the USB memory device into connector J17, then press and release the RESET button. (alternatively, with the board switched off, insert the USB memory device into connector J17 and then switch on the board).
 2. \square will appear on the display: the board automatically loads all the files that are needed to update the board and all the connected accessories from the USB storage device.
 - \square appears on the display while the board is being updated, then, when the update has finished, it reverts to displaying \square ; the display then switches to the FW version and then to the door status display. (It is possible to access the Upload/Download menu by pressing and releasing the **F** button within 3 s from when \square appears on the display).
- It is not necessary to remove the USB storage device.

UPLOAD/DOWNLOAD MENU

1. With the board switched on, insert the USB memory device into connector J17, then press and release the RESET button. (alternatively, if the board is switched off, insert the USB memory device into connector J17 and then switch on the board).
2. \square appears on the display and the USB led turns on.
3. Press and release the **F** button to scroll through the Upload / Download Menu options (see relative table).

UPLOAD OPERATIONS (updating or loading settings)

Press and hold the **+** and **-** buttons simultaneously for at least 3 seconds in order to carry out the procedure displayed.

- the update starts: \square flashes on the display. Release the buttons.
- The procedure is complete when \square appears on the display.

If there are errors \square appears on the display and the red ERR led is lit. To display the error code, press the **+** and **-** buttons simultaneously. The errors are described in the Diagnostics Section, \square Bootloader errors.

- Press **F** to return to the menu.

When finished, remove the USB storage device.

DOWNLOAD OPERATIONS (saving files from board to USB)

Press and hold down the **+** and **-** buttons simultaneously for at least 3 seconds in order to run the function displayed, until \square appears on the display.

Release the buttons and use the **+** or **-** buttons to select the method for saving the file to the root of the USB storage device: \square (overwrite) or \square (add).

Press **F** to confirm.

- The procedure is complete when \square appears on the display.

If there are errors \square appears on the display and the red ERR led is lit. To display the error code, press the **+** and **-** buttons simultaneously. The errors are described in the Diagnostics Section, \square Bootloader errors.

- Press **F** to return to the menu.

When finished, remove the USB storage device.

Files in the ZIPACK	Bootloader	Bootloader
board firmware (LJF)	1.0 and later	0.5
KS EVO firmware (LJE)	E1SL_xx.hex	1400.hex
LK EVO firmware (LJE)	KS_xx.hex	KS EVO.hex
LK EVO firmware (LJE)	LK_xx.hex	LK EVO.hex
SDK EVO firmware (LJE)	SDK_xx.hex	SDK EVO.hex
SDK EVO languages (LJE)	SDKL_xx.bin	SDK EVO_L.bin

Files saved from the board	Bootloader	Bootloader
programming (LJC dC) ^(*)	1.0 and later	0.5
programming TIMER (LJE dE) ^(*)	E1SL.tmr	1400.tmr

^(*) The \square mode saves the file without a suffix and overwrites any existing file with the same name in the USB memory (e.g. E1SL.prg). The \square mode saves the file by adding a 2-digit suffix to the name (e.g. E1SL00.prg) and if there is already a file with the same name in the root of the USB storage device, the number of the suffix is incremented (e.g. E1SL01.prg and so on). **Note:** the suffix must be deleted if you wish to load the file from the UPLOAD MENU.

Files saved from a board with bootloader version 0.5 cannot be loaded onto a board with bootloader 1.0 or later, and vice versa.

BOOTLOADER AND FW VERSIONS

SDK EVO allows the firmware versions (APP) of the SDK EVO, the E1SL board, the DM board, if the DM KIT is installed, and the installed devices to be displayed.

SDK EVO: \square /INFO

\square 8 Upload/Download Menu

LJF	Board FW update
LJE	SDK EVO, LK EVO, KS EVO firmware update including translations of messages displayed by the device
LJC	Load the E1SL board programming.
LJE	Load the TIMER programming
dC	Save the board programming
dE	Save the board's TIMER configuration ^(*)

11. DIAGNOSTICS


LEDS ON THE BOARD

Key to LEDs

- on ○ off
 - * flashing ⚙ board in sleep mode: off with flashing every 5 s
- (←) indicates the condition of the LEDs with the board powered and in standby

- **MAIN (BLUE)** Main power supply unit input
 - main power supply ON ←
 - no main power supply
- **DL2 (BLUE)** Board power +5V
 - board power ON ←
 - no board power
- **DL11 (BLUE)** Accessories power supply (+24 V ↔)
 - accessories power on ←
 - no accessories power
- **USB (GREEN)** USB storage device
 - device present
 - device not present ←
- **ERR (RED)** Error/Alarm in progress
 - error
 - no error/alarm ←
 - * alarm
- **BAT1 (RED)** Battery status
 - battery discharged
 - battery charged ←
 - * battery in use
 - ⚙ battery discharged with no mains power supply
- **BAT2 (GREEN)** Battery charger status
 - battery charger at rest
 - battery charger not working due to mains power failure or fault
 - * battery charger in use
- **SIC_OP (RED)** Safety in opening input
 - input active (sensors engaged)
 - input not active (sensors not engaged) ←
- **SIC_CL (RED)** Safety in closing input (including XFA photocells)
 - input active (sensors engaged)
 - input not active (sensors not engaged) ←
- **SIC_OP (RED) + SIC_CL (RED)** Lit simultaneously = Safety Input STOP
 - input active (sensors engaged)
 - input not active (sensors not engaged) ←
- **EMERG (GREEN)** Emergency Input
 - input active (door opened in emergency)
 - input not active ←
- **OPEN (GREEN)** Open INPUT
 - input active
 - input not active ←

LEDs on the board



24

FW VERSIONS

The FW version of the board appears on the display when you switch it on. SDK EVO allows the FW versions of the SDK EVO, the E1SL board, the DM board, if the DM KIT is installed, and the installed devices to be displayed.

- from SDK EVO: /INFO

... SDK EVO

SDK EVO BOOT VER x.x BOOTLOADER (NOT updatable)

SDK EVO APP VER x.x FIRMWARE (updatable)

SDK EVO LAN VER x.x LANGUAGE file (updatable)

... E1SL

E1SL BOOT VER x.x BOOTLOADER (NOT updatable)

E1SL APP VER x.x FIRMWARE (updatable)

...

AUTOMATION AND CONFIGURED INPUTS STATUS

The STATUS of the automation is displayed in real time on the board display (Status of the automation) and on the SDK EVO.

- from SDK EVO: /PROGRAMMING/INSTALLATION/DOOR STATUS

The STATUS of the configured inputs can be seen:

- from board Advanced Programming: function I_n

- from SDK EVO: /PROGRAMMING/INSTALLATION/INPUTS STATUS

Example Input S2 active:

INPUT STATUS			
IN1	IN2	IN3	IN4
S1	S2	O1	O2
MR	E1	E2	FSW
OK			

ERRORS AND WARNINGS

To display the codes for the current ERRORS/WARNINGS, then see table Errors, Alarms/Info codes.

- from board: simultaneously press and hold the + and -, the display shows:

Er appears on the display and then all the active error/warning codes (e.g. Er 07 18...)

- from SDK EVO: ...

...ERRORS

...WARNINGS



- The ERRORS stop the automation from operating and are indicated by: steady RED ERR LED and status on the display.

- The WARNINGS refer to malfunctions that should be investigated, or operating modes and phases in progress. The ALARMS are indicated by: flashing RED ERR LED. The INFO notifications do not activate LEDs.


9 Status of the automation

	CLOSED
	OPENING
	OPEN
	in PAUSE
	in NIGHT-TIME PAUSE
	CLOSING
	OPEN or STOPPED or CLOSED in EMERGENCY (depending on programming)
	in MANUAL mode
	in NIGHT-TIME mode
	System TEST in progress
	STOPPED
	Safety TEST in progress
	Door ERROR (Press + and - simultaneously to display the ERROR)
	(flashing) SETUP in progress - startup phase
	(flashing) SETUP in progress - closing phase
	(flashing) SETUP in progress - opening phase
	in SLEEP mode (point flashing)
	Programming is in progress via Simply Connect and programming via the board is inhibited

Status of configured inputs - shown on the display:

segment lit = input active


(OFF = segment always off)



25

Displaying errors/warnings on the display:

Er...xx...xx...Er... See Errors, Alarms/Info codes



Led ERR ● (ERRORS)

Led ERR * (WARNINGS)

26

10 Errors, Alarms/Info codes

The 3 digit codes (100 ...) can only be viewed from the SDK EVO.

Errors (number on white background)	Required action (after the intervention RESET is recommended)
Alarms (number on grey background)	Some errors cause the board to AUTORESET: after the error has been active for 30 s the board attempts to RESET (maximum 5 attempts).
Info (i) (number on grey background)	
00 (i) No warnings	
01 Board failure	Perform the RESET. If the problem persists, replace the E1SL. (AUTORESET)
04 Accessories power supply fault	Check the accessories connection for short circuits. Check the current drawn by the connected accessories and that maximum indicated load is not exceeded. Check the accessories protection fuse (on boards fitted with one). Perform the RESET. If the problem persists, replace the control board.
05 FW fault	Make sure that there are no sources of electromagnetic interference too close to the board. Update E1SL FW. (AUTORESET)
07 Motor 1 fault	Motor disconnected or short-circuited. Check the wiring. If the problem persists, replace the motor. (AUTORESET)
08 Motor 2 fault	Motor disconnected or short-circuited. Check the wiring. If the problem persists, replace the motor. (AUTORESET)
09 Power supply fault/No mains power	Check the voltage supplied by the power supply unit. Make sure that there is mains power. (AUTORESET)
10 Low battery	The charge level of the emergency battery is low; it does not allow movements to be carried out. Turn the mains power back on.
11 FAIL-SAFE test failed in closing	Movement is inhibited because the TEST on the input configured as safety has failed. Check the connection and operation of the connected safety device. Check the programming of the input.
12 FAIL-SAFE test failed in opening	Movement is inhibited because the TEST on the input configured as safety has failed. Check the connection and operation of the connected safety device. Check the programming of the input.
15 SETUP inhibited	Make sure that the automation type has been selected correctly, that Night-time or Manual mode has not been selected, that an emergency input is not active, that the automation is NOT operating on the battery due to a mains power failure.
16 Encoder 1 fault	Make sure that the encoder is connected properly. If the problem persists, replace the encoder or the board. (AUTORESET)
18 Access breakout	Access breakout. Re-arm the leaf. Access breakout detected on an input configured as EMERG BREAK OUT.
19 Friction too high	Check the leaves slide smoothly with power supply, battery and motors disconnected. Remove any friction. Check the counter wheel. (AUTORESET)
22 Programming data corrupted	Programming data NOT valid or corrupted. Repeat the programming.
24 Consecutive obstacles in closing	The programmed number of consecutive obstacles in closing has been reached. Remove the obstacle. If the problem persists, repeat the SETUP.
25 LOCK1 fault	LOCK1 fault prevents opening. Check the connection. Remove the cause of the short circuit. (AUTORESET)
27 Motor 1 rotation fault	Check that the belt is connected correctly according to the opening/closing direction of the door.
29 Auxiliary board fault	Check the specific error code via SDK EVO and refer to the errors related to the Double motor (DM) (in this table, from 200 onwards). (AUTORESET)
31 Consecutive obstacles in opening	The programmed number of consecutive obstacles in opening has been reached. Remove the obstacle. If the problem persists, repeat the SETUP.
32 Motion TIMEOUT	The movement is in timeout. Check the manual release. Check the presence of mechanical stops. If limit switches are installed, make sure that they activate correctly. If the problem persists, replace the board or motor.
37 (i) Clock battery discharged or missing	Replace the clock battery.
38 Programming parameters changed	Modified programming, NOT consistent with the SETUP. Restore the previous settings or run the SETUP procedure.
39 Invalid or Missing SETUP	Perform the SETUP. If the problem persists, replace the board or motor.
40 PEOPLE IN - MAX CAPACITY REACHED	The maximum number of people allowed in the premises has been reached, programmed (via Simply Connect) for the SAFE FLOW function.
41 (i) Date/time is missing	TIMER date/time missing. Replace the buffer battery BAT1 - CR2032, then reset the time and date on the board via Simply Connect/SDK EVO.
44 Emergency input active	Emergency input is active. To check which emergency input is active, press the buttons + and - at the same time.
45 (i) TIMER enabled	The TIMER is enabled on the board.
46 (i) TIMER function in progress	A TIMER function mode is in progress via Simply Connect/SDK EVO.
47 Last movement carried out with battery	The automation has carried out the last programmed movement using the battery.
51 (i) Obstacle detected when closing	The notification disappears on the next movement.
52 (i) Obstacle detected when opening	The notification disappears on the next movement.
53 Number of cycles corrupted	Replace the board and carry out maintenance on the system.

Errors (number on white background)		Required action (after the intervention RESET is recommended)
Alarms (number on grey background)		Some errors cause the board to AUTORESET: after the error has been active for 30 s the board attempts to RESET (maximum 5 attempts).
Info (i) (number on grey background)		
54	LOCK anomaly	Perform the RESET. Check the motor block.
55	(i) Pharmacy in progress	PHARMACY OPEN is in progress.
56	Battery operation	The notification remains as long as the automation is operating on the battery due to a mains power failure.
57	(i) Search for opening stop in progress	Slow movement while searching for the OPENING stop. The notification remains as long as the phase is in progress.
58	(i) Search for closing stop in progress	Slow movement while searching for the CLOSING stop. The notification remains as long as the phase is in progress.
59	Lock fault from surveillance kit	Perform the RESET. If the problem persists, replace the motor block.
60	Maintenance request	Ask the installer to carry out scheduled maintenance.
63	Intrusion attempt in progress	An attempt to open the leaf manually has been detected. Start a movement.
65	SETUP IN PROGRESS	The SETUP is in progress. The notification remains as long as the phase is in progress.
67	Battery saving operating	E1SL is operating on battery, in SLEEP mode. To prevent the emergency battery from being discharged, power to the accessories is switched off apart from the SDK EVO.
68	FAIL-SAFE slow motion	The automation moves at slow speed because the TEST has failed on inputs configured as safeties. Check that the safety detector is working. If the problem persists, replace the device.
69	(i) Door opened with SEMIAUTOMATIC OPEN command	The automation is opened from the Semiautomatic OPEN input.
70	Low battery	The charge level of the emergency battery is too low for the movements to be carried out.
71	(i) INTERCOM functionality active	The board is in INTERCOM mode with other boards.
72	INTERCOM fault	No communication between the Master board and the Slave node. Check the connections between the boards.
73	(i) INTERLOCK function active	An INTERLOCK function has been programmed.
74	(i) INTERLOCK mode in progress	The automation is in INTERLOCK mode.
75	(i) INTERCOM SLAVE node in manual or local maintenance	The board is a SLAVE in INTERCOM mode and is in manual/local maintenance.
77	(i) INTERCOM registration in progress	The MASTER automation is registering nodes.
78	(i) AIRSLIDE function in progress	The automation is in AIRSLIDE mode.
79	(i) INTERLEAVES function in progress	The automation is in INTERLEAVES mode.
80	Safeties in opening disabled	The safety in opening devices have been disabled (via Simply Connect).
81	Safeties in closing disabled	The safety in closing devices have been disabled (via Simply Connect).
84	Internal and external sensors disabled	The entry and exit sensors have been disabled (via Simply Connect).
90	Programming in progress	Programming is being carried out via Simply Connect.
91	Accessory board awaiting FW update	The FW update is required for a connected accessory, e.g. SDK EVO. Carry out/repeat the update procedure using a suitable ZIPACK.
99	Control board data deletion	All the E1SL data has been deleted.

DM ERRORS Second Motor BOARD errors		
200	UC FAILURE (Corrupted FW or Corrupted RAM)(DM)	RESET the board. If the error persists, replace the board.
201	MOTOR FAILURE (DM)	Check the motor wiring. RESET the board. If the error persists, replace the DM motor.
202	HIGH MECHANICAL FRICTION (DM)	Manually check smooth sliding of the leaves along the entire space acquired during SETUP.
203	BOARD FAILURE (DM)	RESET the board. If the error persists, replace the board.
204	BOARD FW NOT COMPATIBLE (DM BOARD)	UPDATE the FW of the DM board.
205	MOTOR ROTATION (DM)	INVERT THE DM MOTOR CONNECTION.
209	COMMUNICATION ERROR (DM)	If necessary, update the FW of the automation board.
210	RESET IN PROGRESS (DM)	RESET is in progress.
216	ANOMALY IN COMMUNICATION WITH DM BOARD	RESET the board. Update the FW of the DM board. If the problem persists, replace the DM board.
217	POSITION ERROR (DM)	Incorrect Opening Position. RESET the board. If the error persists, replace the board.
218	OBSTACLE (DM)	Check for obstacles.
219	BOARD ID ERROR	Replace the board.
220	BOARD POWER SUPPLY FAULT (DM)	RESET the board. If the error persists, replace the board.

221	TIMEOUT (DM)	RESET the board. If the error persists, replace the board.
222	BOARD TEST ERROR (DM)	Replace the board.
223	COMMUNICATION ERROR (DM)	Replace the board.
224	FW NOT COMPATIBLE (DM)	Update the FW of the DM board.

SDK EVO Errors

601	FW FAULT SDK EVO	Carry out the RESET procedure. If the error persists, replace the SDK EVO.
602	SDK EVO FAILURE	Carry out the RESET procedure. If the error persists, replace the SDK EVO.
603	SDK EVO LANGUAGE LOADING ERROR	Carry out the RESET procedure. If the error persists replace the SDK EVO.
604	SDK EVO FW ERROR	Update the SDK EVO firmware.
605	BOARD COMMUNICATION ERROR	Check the connections. If the error persists, the communication channel of the board, the SDK EVO, or both are damaged. Replace the board or the SDK EVO.
606	SDK EVO CONNECTED TO A BOARD THAT IS NOT RECOGNISED	Check the type of board.

11 Bootloader (b0) Error codes


b1	UPDATE FILES MISSING FROM USB	Check for files on the USB memory device.
b2	FILE WRITING ERROR	Download the files to the USB storage device again.
b3	DEVICE BEING UPDATED INCORRECT OR MISSING	The connected device on which you are attempting to update the FW is not compatible or not connected.
b4	FW UPDATE ERROR	File read error. Repeat update from USB.
b5	FILE READ ERROR	File corrupted or not the right one, device to be updated.
b6	PASSWORD ERROR	Password file different to the one on the board.
b7	BOARD FAILURE	Replace board.
b8	Microcontroller fault	Replace board.
b9	USB ERROR	USB device not recognised, not formatted with the FAT or FAT 32 file system, or faulty.

11.1 RESET

A Reset has to be carried out to restart the board when the automation is blocked due to an ERROR or an EMERGENCY WITH MEMORY. It can be Reset in one of the following ways:

- from the button on the board: press the RESET button briefly
- from a configured input: activate the specially configured input
- from the SDK EVO: press the two central buttons simultaneously
- from the LK EVO: press the two buttons simultaneously (↑ + ✨)

RESET from button on the board




RESET from configured input

Input	Terminal board	Button
I1		C1
I2	J21	C2
I3		C3
I4		C4
S1	J1	P1
S2	J4	P2
E1	J7	E1
E2		E2

61
RESET


RESET from SDK EVO

HOME PAGE



👉 + 🛠️ (⌚ 5 s)
Release when the flashing Error message disappears.

RESET from LK EVO



↑ + ✨ (⌚ 5 s)
After 5 s the corresponding LEDs (↑ and ✨) start to flash.
Release when the Error LEDs turn off.

11.2 RESTORING FACTORY SETTINGS

The procedure:

- deletes the SETUP data and any TIMER programming
- restores all the programming defaults, including the model of the automation
- resets the cycle counters
- causes the time and date to be lost
- restores the default password (0000)

1. Turn off the mains power supply and disconnect the emergency battery (if present), then turn the mains power back on.
2. Within the first 4 s after switching on (while the display is showing the FW version), press the + - F buttons simultaneously for about 5 s
 - The display indicates --
3. Release the buttons: the display will indicate the status of the automation.

After restoring the factory settings, carry out the set-up procedure again.

RESTORING DEFAULT SETTINGS


To restore programming defaults ONLY:

- from board Basic programming: \square F select default 1 or 2
- from SDK EVO: $\text{⚙️}/\text{PROGRAMMING}/\text{MISCELLANEOUS}/\text{CONFIG.DEFAULT}$ select OK

the following question appears:

DO YOU WANT TO LOAD DEFAULT CONFIG 1? Select OK to confirm, or change option (↑ ↓). DO YOU WANT TO LOAD DEFAULT CONFIG 2?

Restoring factory settings



27

12 Troubleshooting guide

This guide refers to situations not covered in the table **Errors, Alarms/Info codes**.


CONDITION	SUGGESTION
SDK EVO off	There is no mains voltage, the board is operating on battery in NIGHT-TIME mode and energy saving mode. Connection to the board has been interrupted: check the cables and wiring between the SDK EVO and the board. <u>The board is not working correctly: replace the board.</u>
All LEDs are off	Make sure that the primary protection fuse in the power supply unit has not tripped. Make sure that connector J1 has been correctly connected to the board. Check the connection to the power supply unit. <u>The board is not working correctly: replace the board.</u>
MAIN LED off - LED 24 V \equiv on	No mains power and the board is working on battery. The safeties in closing are busy. The emergencies are active. Make sure that OPEN mode has not been activated.
The door DOES NOT CLOSE	Make sure that MANUAL mode has not been activated. Check the motor connection. Make sure that the motor block is not blocked. <u>Check presence of motor power supply voltage.</u> The safeties in opening are busy. The emergencies are active.
The door DOES NOT OPEN	Make sure that MANUAL mode has not been activated. Make sure that NIGHT-TIME mode has not been activated. Check the motor connection. Make sure that the motor block is not blocked. <u>Check presence of motor power supply voltage.</u>
The door CLOSES instead of OPENING and vice versa	<u>Check the belt fitting on the board and perform SETUP.</u> Check correct insertion of the encoder connector.
The door only moves for short stretches	Check the condition of the encoder. <u>Check the condition of flat encoder connection cable.</u>
The door performs movements at very low speed	Make sure that the selected speeds are appropriate. Make sure that the slowing down spaces are appropriate.
The door accelerates or slows down suddenly during an acceleration in opening and/or closing.	Modify the Force and force Time on obstacle (\square F, \square F, $\text{⚙️}/\text{PROGRAMMING}/\text{MOTION}$) Automation in NIGHT-TIME mode. Automation in MANUAL mode.
The door does not perform SETUP	Active internal or external release. The emergencies are active. Motor or encoder not connected, not powered or faulty.

12. LK EVO





The LK EVO allows you to select the operating mode by pressing the corresponding button.

INSTALLATION AND CONNECTION

1. To separate the parts use a flat-head screwdriver to prise them apart.
2. Break the cable knockout.
3. Mark the points on the wall and fasten the support using suitable screws.

 Before connecting the device, disconnect the mains power supply and the emergency battery of the automation system (if present).

4. Connect to the E1SL board:

J8	
	G GND Accessories power supply negative and Common contacts
	TX Data transmission
	RX Data reception
	V +24 V (accessories power supply)



- use a 4 twisted pair U/UTP AWG24 cable with a maximum length of 50 m


 **LK EVO LOCK DEVICE** The lock device is optional. Connect a key command with an NC contact to terminals G and K (see the figure ).

5. Assemble the parts by pressing lightly.



SWITCHING ON Turn power on to the E1SL board.

- The LEDs turn on and off in sequence, then the LED corresponding to the active operating mode remains on.

If the   LEDs are both lit at the same time, it indicates that the automation is in an operating mode that is NOT available on the LK EVO.


OPERATION  **LK EVO Operating buttons** To select the operating mode, press the corresponding button. For special functions, press the 2-button combinations indicated.

ERRORS In the event of errors, the combination of LEDs corresponding to the active error flashes for a few seconds.

WARNINGS In the event of warnings, the combination of LEDs   flashes for a few seconds.



See the table  LED Error Coding on Function selectors.


13 LK EVO Operating buttons





2-button combinations:

 +  (⊙ 5s) **LOCK / UNLOCK** Press for approximately 5 s to Lock/Release the keypad (the LEDs turn on and then off)

 +  (⊙ 5s) **RESET** (the LEDs corresponding to the Error flash until the buttons are pressed, release when they turn off)


WARNINGS To display the active warnings, press and hold the buttons (the LEDs corresponding to the warning flash as long as the buttons are pressed, release when they turn off) (see  LED Warning coding)

 +  (⊙...) **FW VERSION LK EVO** press and hold the buttons to display the FW version of the LK EVO ( LED FW version coding)


 29

Assembling the LK EVO

TX RX G K G V



LK EVO connection Connect to the terminals as shown.



 28

14 LED Error Coding on Function selectors

Errors	↑↓	↔	↑	☸	☾
1 Board failure	*				
4 Accessories power supply fault			*		
5 FW fault	*		*	*	
7 Motor 1 fault	*	*	*		
9 Power supply fault/No mains power		*			
11 Closing FAIL-SAFE test failed	*	*		*	
12 Opening FAIL-SAFE test failed					
15 SETUP inhibited	*	*	*	*	
16 Encoder Fault					*
17 Double contact inputs fault	*	*			
19 Friction too high	*	*			*
22 Programming data corrupted	*		*		
24 Consecutive obstacles in closing				*	*
31 Consecutive obstacles in opening					
25 ANOMALY ON LOCK1		*		*	*
27 Motor rotation fault	*	*		*	*
29 Auxiliary board fault	*		*	*	*
32 Motion timeout				*	
38 Programming parameters changed	*				*
39 SETUP incorrect/missing		*	*	*	*
99 Control board data deletion	*	*	*	*	*

15 LED Warning coding - LK EVO

Warnings	↑↓	↔	↑	☸	☾	👉
37 Clock Battery discharged		*		*		*
44 Emergency input active					*	*
51 Obstacle detected during closure	*				*	*
52 Obstacle detected during opening		*			*	*
54 LOCK fault			*		*	*
56 Battery operation	*		*		*	*
59 Lock fault from surveillance kit	*	*	*		*	*
60 Maintenance requested				*	*	*
68 FAIL-SAFE slow movement		*		*	*	*

16 FW version LED coding - LK EVO


FW version	↑↓	↔	↑	☸	☾	👉
FW 1.0		*		*		
FW 1.1	*	*		*		
FW 1.2			*	*		
FW 1.3	*		*	*		
FW 1.4		*	*	*		
FW 1.5	*	*	*	*		
FW 1.6					*	
FW 1.7	*				*	
FW 1.8		*			*	
FW 1.9	*	*			*	
FW 2.0			*		*	
FW 2.1	*		*		*	
FW 2.2		*	*		*	
FW 2.3	*	*	*		*	
FW 2.4				*	*	
FW 2.5	*			*	*	
FW 2.6		*		*	*	
FW 2.7	*	*		*	*	
FW 2.8			*	*	*	
FW 2.9	*		*	*	*	
FW 3.0		*	*	*	*	
FW 3.1	*	*	*	*	*	

13. KS EVO





KS EVO allows you to select the operating mode by turning the key to the corresponding icon.

INSTALLATION AND CONNECTION

1. Separate the parts (use a flat screwdriver to prise them apart).
2. Break the cable knockout.
3. Mark the points on the wall and fasten the support using suitable screws.

 Before connecting the device, disconnect the mains power supply and the emergency battery of the automation system (if present).

4. Connect to the E1SL board:

J8	
	G GND Accessories power supply negative and Common contacts
	TX Data transmission
	RX Data reception
	V +24 V (accessories power supply)

- use a 4 twisted pair U/UTP AWG24 cable with a maximum length of 50 m
5. Assemble the parts and fix it in place with the screws provided.

SWITCHING ON

Turn power on to the E1SL board.

- The LEDs turn on and off in sequence, then the LED corresponding to the active operating mode remains on (apart from manual mode).

ERROR WARNINGS In the event of errors, the combination of LEDs corresponding to the active error flashes for a few seconds (LED Error Coding on Function selectors).



 Total two-direction automatic



 Door open

 Automatic total one-direction

 Automatic partial two-direction


 Night

 Manual


If the   LEDs are both lit at the same time, it indicates that the automation is in an operating mode that is NOT available on the KS EVO.

 30

Assembling the KS EVO



KS EVO connection Connect to the terminals as shown.



 31

14. SDK EVO

The SDK EVO allows you to select the operating mode of the automation using buttons and menus. The active operating mode is indicated on the display.

The SDK EVO allows the automation to be programmed with wider number of options compared to programming via the board.

SDK EVO LOCK DEVICE

SDK EVO has a safety feature that protects the buttons via a PASS-WORD. Alternatively, it is possible to connect a key command with an NC contact to terminals G and K.

The lock device is optional. The lock device can be programmed from the menu:

/PROGRAMMING/MISCELLANEOUS/SDK EVO KEY

INSTALLATION AND CONNECTION

1. To separate the parts, remove the 2 screws (1).
2. Break the cable knockout (2).
3. Mark the points (3) on the wall and fasten the support using suitable screws.

Before connecting the device, disconnect the mains power supply and the emergency battery of the automation system (if present).

4. Connect to the E1SL board:

J8

	G	GND Accessories power supply negative and Common contacts
	TX	Data transmission
	RX	Data reception
	V	+24V (accessories power supply)

- use a 4 twisted pair U/UTP AWG24 cable with a maximum length of 50 m

OPTIONAL CONNECTION - key command SDK EVO Connect a key command with an NC contact to terminals G and K (see the figure).

5. Assemble the parts and fix in place with the screws (1).
6. Fasten the display using the screw (4) and insert the screw cover (5).


SWITCHING ON

Turn power on to the E1SL board. The device turns on and displays a series of screens:

- power-on screen
- Bootloader: displays the Bootloader version (x.x NOT updatable)
- Firmware: displays the FW version (x.x)
- HOME PAGE: ready


Note: if no buttons are pressed, after 2 minutes the display reverts to the HOME PAGE.

Assembling the SDK EVO




SDK EVO connection

Connect to the terminals as shown.



Screen sequence when switched on



HOME PAGE

The 4 buttons activate the commands associated with the icons above:

- ☾ = sets the NIGHT mode
- 👤 = sets MANUAL mode
- 🔧 = accesses the MENU in order to configure all the board parameters
- ➔ = switches to MODFUN: additional operating modes

Each time the NIGHT or MANUAL button is pressed, the mode is enabled (icon highlighted on the display) and disabled.

Every time it is changed, the mode that is enabled is immediately updated on the display.

Symbols on the HOME PAGE:

🔔	current indications
T	TIMER active
🔒	SDK EVO locked
*	USER PASSWORD disabled

RESET - LOCK/RELEASE

2-button combinations on the HOME PAGE:

- ☾ + ➔ (5 s) **LOCK / UNLOCK** Press for approximately 5 s to Lock/Release the keypad (the 🔒 icon appears)
- 👤 + 🔧 (5 s) **RESET** (press for approximately 5 s, until the flashing Error message disappears. After a series of screens it reverts to the HOME PAGE)

PASSWORD (PSW)

When the PASSWORD screen appears, a 4-digit password must be entered. There are 2 passwords: **USER PSW** and **TECHNICIAN PSW**. By default, both are: **0000**.

The technician password gives access to the restricted functions (PROGRAMMING), but also to those of the user.

No password is required to select the NIGHT, MANUAL or MODFUN operating modes via a button.

Entering the PSW

- select (↑↓) and confirm (OK) each digit of the PSW in succession
- the device recognises the **USER PSW** or **TECHNICIAN PSW**

If a PASSWORD IS NOT RECOGNISED "WRONG PASSWORD" appears on the display. Press OK to go back to the HOME PAGE.

Changing the PSW:


🔧/PASSWORD

Changing the PSW is recommended when you carry out programming for the first time.

- select and confirm the password to be modified: **USER PSW** or **TECHNICIAN PSW**
- select (↑↓) and confirm (OK) the digits of the PSW one by one, then confirm the complete PSW


HOME PAGE

- name of the door (e.g. A1400 AIR)
- current day and date, or people counting (if SAFE FLOW is enabled)
- operating mode (MODFUN)
- time



- NIGHT (PSW)
- MANUAL (PSW)
- MENU (PSW)
- MODFUN

PASSWORD



Default password: 0000



	☾	👤	🔧	➔
USER	without PSW	without PSW	PSW*	without PSW
INSTALLER	without PSW	without PSW	PWD	without PSW

* the TECHNICIAN PSW is required to access the programming functions in the MENU 🔧

ENGLISH
Translation of the original instructions

MODFUN

1. Access MODFUN by pressing the button on the HOME PAGE.
2. Using the buttons, select the operating mode, the direction (Two-directional, EXIT Only, ENTRY Only) and the opening percentage (Total or Partial).
3. Confirm the MODFUN using the **OK** button, this then takes you back to the HOME PAGE.

MENU

1. Access the functions menu by pressing the button on the HOME PAGE.
2. Enter the USER or TECHNICIAN PSW.
3. The display shows the functions. Select the available functions using the buttons:
 - LANGUAGE
 - PROGRAMMING (TECHNICIAN PSW required)
 - ERRORS
 - WARNINGS
 - INTERCOM (only available on the MASTER board specified in PROGRAMMING/INTERCOM)
 - CYCLES COUNT
 - DATE/TIME
 - TIMER
 - PASSWORD
 - INFO
4. Press the **OK** button to access the selected function and then the and **OK** buttons to display it or set it.
5. Confirm by pressing the **OK** button, it takes you back to the MENU. Press the **ESC** button to go back to the HOME PAGE.

PROGRAMMING

/PROGRAMMING

1. Access the functions menu by pressing the button on the HOME PAGE. Select PROGRAMMING and press **OK**.
2. The list of programmable functions appears. Select and set the individual options using the and **OK** buttons.
3. Press the **OK** button repeatedly to return to the list of programmable functions and then to the MENU. Press the **ESC** button to go back to the HOME PAGE.

MODFUN examples

Automatic Two-directional, with Partial opening:



Door open, with Total opening:



INTERLOCK, EXIT only, with Total opening:



MODFUN

100%

OK

XXX XXXX

AUTOMATIC TWO-DIRECTIONAL

TOTALLY OPEN

INTERLOCK

TWO-DIRECTIONAL

EXIT ONLY

ENTRY ONLY

AUTO MANUAL

TOTAL

OPENING

To select INTERLOCK press and hold or for at least 3s.
Available on the MASTER board, if enabled (Section INTERCOM).

MENU



- the selected function is indicated with >
- buttons to select the function
- **ESC** button to go back to the HOMEPAGE
- **OK** button to access the function/confirm the programming and go back to the MENU

MENU

- > 1 LANGUAGE
- > 2 PROGRAMMING
- > 3 ERRORS
- > 4 WARNINGS

ESC






OK












2 PROGRAMMING OK → see specific diagram

3 ERRORS OK → see § Diagnostics

4 WARNINGS OK → see § Diagnostics





All the menus are described below.

The options that are ONLY available from the SDK EVO are indicated with (*).

MENU 1 LANGUAGE

Select from the list provided.

MENU 2 PROGRAMMING



The menu is only accessible if the TECHNICIAN password has been entered.

If a different password has been inserted, it is indicated: WRONG PASSWORD.

■ 1 Simply Connect

If you wish to enable Simply Connect, select a channel (CH):

1, 2, 3, 4, 0 = Simply Connect disabled

■ 2 DOOR TYPE

Select the model of the automation from the list provided.

SF1400 opens 2 additional menus:

LEAF NUMBER: 1 LEAF, 2 LEAVES

PASSING SPACE.

with 1 LEAF selection: ≥ 75 cm, ≤ 65 cm, >65 cm and <75 cm

with 2 LEAVES selection: ≥ 150 cm, ≤ 130 cm, >130 cm and <150 cm

■ 3 INPUTS / OUTPUTS

(*) The NO/NC contact logic can only be programmed via the SDK EVO

(*) The courtesy LIGHT outlet time can only be programmed via the SDK EVO

Select the input or output from the list provided, assign the configuration and select the type of contact (NO, NC).

INPUTS I1, I2, I3, I4

If an input is configured as a SAFETY, you are required to set the TEST:

ENABLED, DISABLED

OUTPUTS O1/O2

The LIGHT option requires the time to be set: 1...240 s

INPUTS S1-S2

As Inputs I1- I4.

INPUTS E1 / E2

As Inputs I1- I4.

PHOTOCELLS XFA

Allows you to select: DISABLED, 1 PAIR, 2 PAIRS

■ 4 MOTION

OPENING

Allows you to program:

SPEED: level 1...10

SLOWDOWN: Slowdown space at end of travel 0...200 cm

SLOWDOWN SPEED Slowdown speed at end of travel level 1...3

STRENGTH: level 1...10

STRENGTH DURATION: 0.1...3.0 s

ACCELERATION: level 1...10

DECELERATION: level 1...10

CLOSING

Allows you to set the same parameters as found under OPENING.

BRAKING

Allows you to program the deceleration for the reverse movement: level 1...5

STOP MOV

Allows you to bring the stop position forwards with respect to the opening stop: level 1...10 (0 = minimum distance)

■ 5 TIMING

Allows you to program:

PAUSE TIME 0...30 s

NIGHT PAUSE TIME: 0...240 s

NIGHT SENSOR DELAY: 0...240 s

■ 6 ENERGY SAVING

Allows the Energy Saving function to be enabled/disabled (relative § Section).

■ 7 BATTERY KIT

Allows the emergency battery kit to be enabled, specifying the movements carried out in the various operating modes.

FUNCTION

DISABLED, UNTIL LAST MOVEMENT, LAST MOVEMENT ONLY

LAST MOVEMENT: OPENING, CLOSING

FUNCTION NIGHT

LAST MOVEMENT ONLY, UNTIL LAST MOVEMENT

LAST MOVEMENT NIGHT: OPENING, CLOSING

BATT.LOW OPENING: ENABLED, DISABLED

OPENING TEST: ENABLED, DISABLED

■ 8 KIT LOCK

Allows you to program the way the motor block operates (if installed).

TYPE: DISABLED, XB LOCK, XM LOCK (not available for A1000)

FUNCTION

Defines operating modes in which motor block is activated:

DISABLED, NIGHT, NIGHT+MONODIR, NIGHT+OPENED, NIGHT+CLOSED ALWAYS

SURVEILLANCE KIT

ENABLED, DISABLED the surveillance kit on the motor block must be disabled if it is not installed

FUN. BATTERY

Defines the way the motor block operates when the automation is operating on the battery:

NIGHT, STANDARD, ALWAYS OPEN

■ 9 INSTALLATION

Menu specific to operations carried out during start-up.

MOTOR ROT.

Allows the direction of rotation of the motor to be reversed:

STANDARD, NOT STANDARD (factory setting = STANDARD)

2ND ENGINE KIT

ENABLED, DISABLED enables the double motor kit, if installed

START SETUP

Follow the instructions in the § SETUP section.

Confirm to carry out the SETUP.

INPUTS STATUS

Allows the active inputs to be displayed (see § Diagnostics Section).

DOOR STATUS

Allows the status of the door to be displayed (e.g. SETUP IN PROGRESS).

OTHER BOARD DATA

Allows the following data to be displayed:

V_MAIN input voltage to the board in Volts

V_BATT battery voltage in Volts

V_ACC accessories voltage in Volts

I_MOT motor current draw in Amperes

POS leaf position in cm

■ 10 INTERCOM

Program the NODE from the INTERCOM network if provided (relative § Section).

ID

Identifies the NODE (ID of the board connected to SDK EVO):
DISABLED, 1...15

INTERLOCK

Allows INTERLOCK to be enabled (relative § Section):
DISABLED, NO MEMORY, WITH MEMORY

INTERLEAVES

Allows INTERLEAVES to be enabled (relative § Section):
ENABLED, DISABLED

AIRSLIDE

Allows AIRSLIDE to be enabled (relative § Section):
ENABLED, DISABLED

NODES ENTRY

This is available if the SDK EVO is connected to the board ID=1 and allows all the boards in the network to be recognised.

NODE LIST

This is available if the SDK EVO is connected to the board ID=1. Displays the NODES that have been registered and the relative information for each one:
INFO, ERRORS, WARNINGS, CYCLES NUMBER, MAINTENANCE.

MAINTENANCE

One or more SLAVE boards can be disconnected temporarily from the INTERCOM network mode using the MASTER board.

Select and confirm an ID, then select MAINTENANCE and for the selected ID choose:

LOCAL = (NOT available for ID=1) the operating mode of the door is independent of the network INTERCOM

MANUAL = door in MANUAL

DISABLED = the door resumes operation in network mode INTERCOM

■ 11 MISCELLANEOUS

CONFIG. DEFAULT

The following question appears:

DO YOU WANT TO RELOAD DEFAULT CONFIG 1? Select OK to confirm, or change option (↑ ↓). DO YOU WANT TO LOAD DEFAULT CONFIG 2?

PARTIAL OPEN (NOT for SF1400 and GBF1500)

Defines the opening percentage in PARTIAL OPEN mode

20...100% Adjustment step 1%.

Then select how partial open is carried out:

STANDARD partial open is fixed at the set percentage

100% INT+EXT partial open increases automatically to 100% if the internal and external sensors are engaged at the same time (it reverts to the set percentage when at least one sensor is released).

BOARD'S DISPLAY

Allows programming from the board to be enabled/disabled.

NOT BLOCKED programming from the board is enabled

BLOCKED programming from the board is disabled

OP. SAFETY FUNC.

Defines the way one or more inputs configured as an OPENING SAFETY operate.

Low Energy carries out movement at low speed

STOP stops the automation

INTRUSION

Defines the operation in response to an attempt to open the automation manually.

DISABLED does not actuate the motor

KEEP CLOSED actuates the motor in order to keep closed (with an adjustable force)

PULL & GO the motor completes the opening (NOT active with battery operation)

PARTIAL PHARMACY (NOT for SF1400 and GBF1500)

Defines the opening percentage of the PHARMACY OPEN command in NIGHT mode

1...95%

SDK EVO KEY

Defines the operation of a key switch connected to the SDK EVO:

BLOCK SDK EVO works with password when the contact is open and is locked when the contact is closed.

WITHOUT USER PSW SDK EVO works without a password when the contact is open and with a password when the contact is closed (* is indicated on the HOME PAGE)

CONSECUTIVE OBST.

Defines the number of consecutive obstacle detections after which the automation stops in an error state.

CLOSING DISABLED (= 25 detections), or 1...10 detections

OPENING (as above)

TEST ERROR

Allows the movement to be activated in Low Energy mode or to inhibit movement if there is a TEST ERROR on an input configured as SAFETY.

ENABLED = movement inhibited

DISABLED = movement in Low Energy mode

BACKLIGHT DISPLAY

Allows the backlighting of the SDK EVO to be enabled/disabled.

ALWAYS Backlighting is always active.

DISABLED The backlighting is activated when the buttons are pressed (it turns off after 2 min if no buttons are pressed).

ELASTIC KIT (NOT for SF1400 and GBF1500)

Allows the elastic anti-panic kit to be enabled/disabled. ENABLED, DISABLED

MENU 3 ERRORS

The display shows current errors (§ Diagnostics Section).

(*) The 3 digit codes (100 ...) can only be viewed from the SDK EVO.

MENU 4 WARNINGS

The display shows current warnings (§ Diagnostics Section).

(*) The 3 digit codes (100 ...) can only be viewed from the SDK EVO.

MENU 5 COUNTERS

■ 1 CYCLECOUNTER

CYCLES NUMBER

Displays the number of cycles carried out, divided into ABSOLUTE (NOT resettable) and RELATIVE cycles.

MAINTENANCE

Allows a maintenance request to be enabled according to the cycles carried out or on a programmed date. If both options are enabled, a maintenance request is issued when the first event is reached (CYCLES or DATE).

****enter the TECHNICIAN PSW and confirm.

Go to MAINTENANCE CYCLES select: DISABLED or ENABLED

Specify the number of RELATIVE cycles for maintenance (step 10000, maximum 1000000) and confirm.

Go to MAINTENANCE DATE select: DISABLED or ENABLED and set the date: 00/00/00

CYCLES RESET

Enter the technician PSW and confirm. To reset the RELATIVE cycles counter, confirm with OK. This command requires confirmation The ABSOLUTE cycles counter can only be reset using the restore factory settings procedure (see relative § Section).

■ 2 SAFE FLOW

This function counts the people entering/leaving the premises for capacity and queue management and sets the number of people allowed in.

FUNCTION

DISABLED = SAFE FLOW disabled

PEOPLE IN AUTO = enables counting and alarm. Alarm (40) is triggered when the maximum number of people allowed is reached.

PEOPLE IN EXIT ONLY = enables counting and alarm. Alarm (40) is triggered when the maximum number of people allowed is reached and the door does not allow people to enter until the number of people in the premises falls below the set threshold.

PEOPLE IN NUMBER

Sets the number of people allowed in (1...1000)

PEOPLE IN UPDATE

It allows the number of people in the premises (0 ... 1000) to be corrected manually

if necessary

NOTE: In an INTERCOM network (see Section § INTERCOM) the SAFE FLOW (PEOPLE IN NUMBER, PEOPLE IN UPDATEFUNCTION) has to be programmed on the MASTER unit. Then SAFE FLOW can also be enabled on the individual SLAVE boards via the PEOPLE IN SLAVE parameter, displayed only on the SLAVE boards.



For the connections, configurations and devices required, see the SAFE FLOW instructions.

MENU 6 DATE / TIME

■ SET DATE

Set date in dd/mm/yy.

■ SET TIME

Set time in HH:mm.

MENU 7 TIMER

Refer to the § TIMER Section.

Programming allows the operating mode to be set for the required TIME SLOTS for one or more days of the week. Set any JOLLY slots that may be required. When the TIMER is active, the operating mode is set automatically according to the set time bands and the warning T appears on the HOME PAGE. To change the operating mode manually that was activated by the TIMER, it must be disabled.

■ 1 TIMER STATUS

Allows the TIMER to be enabled/disabled

ENABLED = run the TIMER function

DISABLED = DO NOT run the TIMER function, but the programming remains in memory

■ 2 MONDAY... 8 SUNDAY

Allows the days of the week to be programmed: select the day, select the TIME SLOT, assign the operating mode and set the BEGINNING and the END time of the TIME SLOT. Carry out the same procedure for the other TIME SLOTS required.

■ 9 MON-SUN, 10 MON-FRI

Allows groups of days to be programmed quickly with the same TIME SLOTS: select a group of days (from MON-SUN or from MON-FRI). Select the TIME SLOT, set the BEGINNING and END time and assign the operating mode. Carry out the same procedure for the other TIME SLOTS required. Apply the programming to the group of days by selecting APPLY; any settings already made for individual days will be overwritten.

■ 11 JOLLY

Allows the operation of the TIMER to be set in the JOLLY slots (one or more days that require a different programming): program the required JOLLY TIME SLOTS (operating mode and the BEGINNING and END) time.

■ 12 JOLLY SLOTS

To apply the JOLLY programming to individual days or to SLOTS of multiple days: enable a SLOT, specify the BEGINNING and END date for the SLOT. Carry out the same procedure for the other INTERVALS required.

MENU 8 PASSWORD

The personnel allowed to use the password, to select the automation's operating modes (USER) must keep the password confidential.

The USER is ONLY allowed to modify the USER PSW. The TECHNICIAN may edit both passwords.

■ TECHNICIAN PSW

Allows the TECHNICIAN PSW to be modified.

Enter the current TECHNICIAN PSW, then the new NEW PSW and press OK. Re-enter the NEW PSW and confirm with OK. If the PSW is not repeated correctly, the SDK EVO continues to request confirmation.

■ USER PSW

Allows the USER PSW to be modified.

**** Enter the TECHNICIAN PSW or the current USER PSW, then the new NEW USER

PSW and press OK. Re-enter the NEW PSW and confirm with OK. If the PSW is not repeated correctly, the SDK EVO continues to request confirmation.

MENU 9 INFO

Allows the firmware versions (APP) of the SDK EVO, the E1SL board, the DM board, if the DM KIT is installed, and of the installed devices to be viewed.

EXAMPLE:

```
SDK EVO  BOOT  VER 0.3  (Bootloader - not updatable)
SDK EVO  APP   VER 4.2  (Firmware)
SDK EVO  LAN   VER 3.3  (Language)
E1SL BOOTVER 3.0  (Bootloader - not updatable)
E1SL APP  VER 4.5  (Firmware)
DMRD     VER 4.0  (Firmware)
```

If Simply Connect is enabled, the following data is also displayed:

ID: unique identifier for (E1SL) board - 23 digit alphanumeric code
CH: no. of the programmed communication channel

15. SIMPLY CONNECT

The Simply Connect CLOUD platform allows remote communication with the automation.

Simply Connect requires a FAAC connectivity module accessory, which is chosen according to the technology to be used:

- XMB (GSM for mobile, Bluetooth Low Energy technology)
- XWBL (WiFi, LAN, Bluetooth Low Energy technology).



To safeguard people and property, the automation must be supervised and there must be not be any unauthorised persons present for the entire duration of operations carried out remotely (SETUP and/or modifications to operating parameters).



Simply Connect requires E1SL firmware version **FW 4.0** or later. When programming is taking place via Simply Connect, programming via the board/SDK EVO is inhibited (☞ on the display).

1. Insert the connectivity module into the dedicated plug-in connectors.
2. Switch on power on to the board; check the signalling LEDs (see the instructions for the connectivity module used).
3. Enable Simply Connect one the board and assign a communication channel (CH).

- from Board:

Basic programming, function ☞:


1 = CH 1, 2 = CH 2, 3 = CH 3, 4 = CH 4, ☐ = NOT enabled


or

- from SDK EVO:

🔑/PROGRAMMING/Simply Connect/1..4 (0 = NOT enabled)

4. Install the Simply Connect Pro App (see the instructions for the connectivity module used).





FAAC

FAAC S.p.A. Soc. Unipersonale
Via Calari, 10 - 40069 Zola Predosa BOLOGNA - ITALY
Tel. +39 051 61724 - Fax +39 051 09 57 820
www.faac.it - www.faacgroup.com

