

# INSTRUCTION MANUAL DAAB DRIVE UNIT MT/MK2/MA2/M10

Issue 1



FAAC Nordic AB BOX 125, SE-284 22 PERSTORP SWEDEN TEL. +46 435 77 95 00 support@faac.se, www.faac.se

## Innehåll

EU Declaration of incorporation	3
Safety	4
General	4
Packing, transport and unpacking	4
General	4
Introduction	5
Intended use	5
Machine marking	5
Manufacturer	5
Drive unit MA2/MK2	6
Function description	6
Design and function	6
Dimensions	6
Technical specification	7
Electric motors	7
Gears	7
Installation and commissioning	7
General installation	7
Side installation	8
Mounting plate	8
Drive arm	8
Gate mounting and link arm	9
Top mounting	9
Bracket & mounting plate	9
Drive arm	10
Gate mounting	10
Link arm	10
Top mounting with limited lateral space	11
Bracket & mounting plate	11
Drive arm	11
Gate mounting	11
Mounting plate for the swing arm bracket	12
Link arm	13
Wing mounting	14
Bracket & mounting plate	14
Drive arm	14
Installing the drive unit	15
Drive unit MT	16
Function description	16
Design and function	16
Dimensions	16
lechnical specification	1/
Electric motors	1/
Gears	1/
Installation and commissioning	1/
General installation	17
Side installation	18
Mounting plate	18
Drive arm	18
Gate mounting and link arm	19

Top mounting	20
Bracket & mounting plate	20
Drive arm	20
Gate mounting	20
Link arm	21
Top mounting with limited lateral space	22
Bracket & mounting plate	22
Drive arm	22
Gate mounting	22
Mounting plate for the swing arm bracket	22
Link arm	23
Adjusting the drive unit	25
Disengagement	25
Quick release	25
Release handle	25
Electrical connection	26
General	26
Engaging the electric motor	26
Limit positions	27
Maintenance and service	27
General	27
Lubrication	27
Oil filled gearbox	27
Open gearbox	28
Spare parts	28
Fault search	28
In the event of a blockage	28
In the event of a collision	28
The motor is running but the gate is not moving	28

## EC Declaration of Conformity (original version)

### Manufacturer

FAAC Nordic AB Box 125, 284 22 Perstorp, Sweden Telephone: +46 (0)435 77 95 00, Fax: +46 (0)435 77 95 29

Person authorised to compile the technical documentation Ulf Ivarsson, FAAC Nordic AB, Box 125, 284 22 Perstorp, Sweden

General description and type designation Drive unit for industrial doors and gates MT, MK2, MA2, M10

We hereby declare that the MT, MK2, MA2, M10 drive unit meets the relevant requirements of Machinery Directive 2006/42/EC, EMC Directive 2014/30/EU, Low Voltage Directive 2014/35/EU, RoHS Directive 2011/65/EU incl. (EU) 2015/863, REACH 1907/2006/EC and Construction Products Regulation 305/2011.

The drive units MT, MK2, MA2, M10, where applicable, compliant with the following standardised norms:

- SS-EN 13241+A2:2016 Industrial, commercial and garage doors and barriers Product standard, performance characteristics.
- SS-EN 13849-1:2016 Safety-related parts of control systems Part 1: General principles for design.
- SS-EN 60204-1 Safety of machinery Electrical equipment of machines Part 1: General requirements.
- SS-EN 60335-1 Household and similar electrical appliances Safety Part 1: General requirements
- SS-EN 60335-2-103 Household and similar electrical appliances Safety Part 2-103: Particular requirements for drives for barriers, doors and windows.
- SS-EN 61000-6-2 Electromagnetic compatibility (EMC) Part 6-2: Generic standards Immunity for industrial environments.
- SS-EN 61000-6-3 Electromagnetic compatibility (EMC) Part 6-3: Generic standards Emission standard for residential, commercial and light-industrial environment.

This EC declaration of conformity relates to drive units MT, MK2, MA2, M10 in the condition in which it is released to the market, and does not cover components added and/or modifications made thereafter. Nor does it relate to third-party equipment or to interfaces between third-party equipment and said equipment supplied by FAAC Nordic AB. The instruction/installation manual for drive units MT, MK2, MA2, M10 must be followed and attention must be paid to risks in the installation of the industrial door or gate.

## **Declaration of performance**

Intended use of the construction product

Drive unit intended for installation on industrial doors or gates for use in industry, commercial areas and residential areas that are open to the public, and intended to provide secure access for people, goods and vehicles.

System for the assessment and continuous verification of the performance of the construction product System 3

## Performance

Property	Performance	Harmonised standard	
Force exerted		SS-EN13241 + A2:2016	
Safety edges	Performance level c	SS-EN 13849-1	
Load guard	Performance level c	SS-EN 13849-1	

Perstorp, 2024-05-31

Ola Hansson, MD



## Safety

## • General

Read through the entire instruction manual carefully before unpacking, installing and using the equipment. Pay particular attention to the safety paragraphs in the text.

There is a risk of serious injury or material damage if the prescribed precautionary measures are not taken.

Sections of text warning of hazards are sorted by severity and have the headings DANGER, WARNING and NOTE! which have the following significance:



## DANGER

This means that there is a danger to the life or health of the user if

the relevant precaution is not taken.



## WARNING

This means that there is a risk of bodily injury or damage to the machine if the relevant precaution is not taken.

•

NOTE!

This means that important information requires the full attention of the reader.

## Packing, transport and unpacking

WARNING

General

## NOTE!

It is important to secure the drive unit properly in its packaging and to ensure that moving parts are not under tension during transport.

Immediately on arrival check that the consignment is as agreed.



Treat the drive unit carefully during handling and transport.

Lifting the drive unit



WARNING Do not lift the drive unit by its moving parts or protective cover.

## Table of weights excluding the drive arm and link arm:

Drive unit	MT	MA2	MK2	M10
Weight, kg	16	23	25	60



## Introduction

## • Intended use

To open and close swing gates, leaf doors and folding doors. Drive units are intended for use in normal indoor and outdoor environments. All other use is prohibited.

## · Machine marking

WE OPEN	ABB DOORS FOR YOU		IP X4
Art.no		Ratio	
Ser.no		Year	
	Perstorp, Sweden www.faac.se		

The plate must not be removed or made illegible!

## The identification plate contains the following information:

- Art.no: Part number
- Ser. no: The serial number of the drive unit (used in all communication with FAAC Nordic AB regarding spare parts).
- Ratio: The gear ratio of the gearbox in the drive unit
- Year: The year in which the drive unit was manufactured.
- IP: The IP rating of the drive unit.

## • Manufacturer

FAAC Nordic AB Box 125 SE-284 22 Perstorp, Sweden Telephone: +46 435 77 95 00 Fax: +46 435 77 95 29 E-mail: info@faac.se Website: www.faac.se







• Technical specification

## Electric motors

The design, rated output and connection dimensions of the motors meet the requirements contained in Swedish and European Standards according to IEC 31-1 and 72 together with SS4260101 and SS4360102.

DANB

FA

Ratings for motor	Ratings for motor types used in the MK2, MA2 and M10							
Motor type ~	Hz	Output kW	Voltage V	Current A	Motor speed rpm	Type of opera- tion*	Ingress protection rating	Thermal switch
SKh 714B2 3-phase	50	0.37	220-240 D 380-440 Y	2.2-2.4 1.25-1.4	1370 1370	\$3 25%	IP54	With or without a thermal switch**
SKh 714B2 3-phase	50	0.37	525	0.8	1360	S1	IP55	No thermal switch
SEMKh 714B2 1-phase 10uF/450V	50	0.25	240	2.6	1350	S1	IP54	With or without a thermal switch**

\*S1 = Continuous operation. The motor can be subject to full load in continuous operation.

\*S3 = Intermittent operation. The motor must not be subject to full load for more than 25% of the 10 minute duty cycle. In practice the motor is not subject to full load for more than one second just as it starts.

\*\*The motor is available both with and without an integrated thermal switch. If the motor has a thermal switch there is a red label on the motor indicating this.

## Gears

Select the opening speed taking account of the size and weight of the gate. The basic rule is to select a lower speed for large gates.



WARNING Too high an opening speed can result in trapping forces being too large despite the use of a sensing strip.

## MK2/MA2

Electric motor pulley	GEARING	MOTOR SHAFT SPEED	TORQUE	OPENING TIME
	i	rpm	Nm	seconds
40	1400	1,00	1600	30
50	1150	1,25	1275	24
71	800	1,77	900	17
100	570	2,49	650	12
125	450	3,12	510	9
140	400	3,49	450	8

• Installation and commissioning

## General installation

donoral motan	
	WARNING Always start installation with a run through of the points in the: "Pre-installation checklist".
	WARNING The drive unit must be installed so that no unprotected moving parts are lower than 2,500 mm.
	WARNING Always use the fasteners prescribed in the assembly drawing with regard to: property class, dimensions, length and quantity.



## • Side installation



## Mounting plate



The mounting plate is not manufactured by FAAC. The measurement from the floor or other permanent entry level to the lower edge of the mounting plate should be at least 2,550 mm. The dimensions of the mounting plate should be 200 mm x 400 mm and it should be at least 8 mm thick. It must be positioned according to the enclosed assembly drawing. The mounting plate is to be anchored so that it can withstand a torque of 2,000 Nm.

Lightweight concrete wall for example – through-going M10 bolts are used. Concrete – 10 mm resin anchor.

Steel building – square tube onto a fixed building structure. The mounting plate is also welded onto the gate surround.

Drive arm



## INSTRUCTION MANUAL MT, MA2, MK2, M10 DRIVE UNIT

# DARB FAAC

## Gate mounting and link arm



• Top mounting



Bracket & mounting plate



Drive arm



Install the drive arm by removing the bolt and washer / retaining ring on the output shaft from the drive unit and pressing the arm into place. Then reinstall the bolt and washer / retaining ring.

Gate mounting



Screw the gate mounting into place using two M8 bolts according to the assembly drawing.

Link arm



## • Top mounting with limited lateral space







Centre the plate horizontally above the gate opening. Height dimensions in accordance with a separate assembly drawing. Then weld the motor plate onto the mounting plate.

DANB

FZZ

Drive arm



Install the drive arm by removing the bolt and washer / retaining ring on the output shaft from the drive unit and pressing the arm into place. Then reinstall the bolt and washer / retaining ring.

Gate mounting



## Mounting plate for the swing arm bracket



## Link arm



# • Wing mounting

FA

D4NB



## Bracket & mounting plate



## Drive arm



## • Installing the drive unit

Installation of the drive unit is common to all types of mounting.

The motor is located in different holes depending on the angle at which it is positioned. Viewed from the left this is 90, 100 and 110 degrees. The angle to be used is indicated in the assembly drawing supplied with the unit.





Dimensions



## • Technical specification

## Electric motors

The design, rated output and connection dimensions of the motors meet the requirements contained in Swedish and European Standards according to IEC 31-1 and 72 together with SS4260101 and SS4360102.

Ratings for motor types used in the MT:								
Motor type ~	Hz	Output kW	Voltage V	Current A	Motor speed rpm	Type of opera- tion*	Ingress protection rating	Thermal switch
SKg 63-2B 3-phase	50	0.25	220-240 D 380-420 Y	1.1-1.2 0.65-0.72	2760	S1	IP55	With or without a
	60		440-480 Y	0.65-0.72	3310			thermal switch**
STKg 63X-4C 3-phase	50	0.25	220-240 D 380-420 Y	1.65-1.8 0.95-1.0	1400	S1	IP55	With or without a
	60	0.30	440-480 Y	0.95-1.0	1680			thermal switch
SEMKg 63-2B 1-phase 8uF/450V	50	0.18	240	1.45	1360	S1	IP55	With or without a thermal switch**
SEMKg 63-4C 1-phase 8uF/450V	50	0.18	240	1.70	2760	S1	IP55	With or without a thermal switch**

\*S1 = Continuous operation. The motor can be subject to full load in continuous operation.

\*S3 = Intermittent operation. The motor must not be subject to full load for more than 25% of the 10 minute duty cycle. In practice the motor is not subject to full load for more than one second just as it starts.

\*\*The motor is available both with and without an integrated thermal switch. If the motor has a thermal switch there is a red label on the motor indicating this.

## Gears

Select the opening speed taking account of the size and weight of the gate. The basic rule is to select a lower speed for large gates.

WARNING Too high an opening speed can result in trapping forces being too large despite the use of a sensing strip.

ELECTRIC MOTOR OUTPUT SPEED	GEARING	MOTOR SHAFT SPEED	TORQUE	OPENING TIME
rpm	i	rpm	Nm	seconds
1400	750	1,90	550	16
2800	750	3,80	275	8

## • Installation and commissioning

General installation

	WARNING Always start installation with a run through of the points in the: "Pre-installation checklist".
<u>\</u>	WARNING The drive unit must be installed so that no unprotected moving parts are lower than 2,500 mm.
	WARNING Always use the fasteners prescribed in the assembly drawing with regard to: property class, dimensions, length and quantity.

## • Side installation



## Mounting plate



## Gate mounting and link arm



## • Top mounting

**F**4/

![](_page_19_Picture_2.jpeg)

## Bracket & mounting plate

DANB

![](_page_19_Picture_4.jpeg)

Install the drive arm by removing the bolt and washer / retaining ring on the output shaft from the drive unit and pressing the arm into place. Then reinstall the bolt and washer / retaining ring.

Gate mounting

3

![](_page_19_Picture_7.jpeg)

Screw the gate mounting into place using two M8 bolts according to the assembly drawing.

## INSTRUCTION MANUAL MT, MA2, MK2, M10 DRIVE UNIT

## Link arm

6

![](_page_20_Picture_2.jpeg)

Position the link arm between the drive arm and gate mounting. Screw it into place using M12 bolts and washers.

FAA

DANB

Adjust it by undoing one bolt and then screwing the arm out or in at the gate mounting.

## • Top mounting with limited lateral space

![](_page_21_Picture_3.jpeg)

## Bracket & mounting plate

![](_page_21_Picture_5.jpeg)

Drive arm

![](_page_21_Picture_7.jpeg)

Install the drive arm by removing the bolt and washer / retaining ring on the output shaft from the drive unit and pressing the arm into place. Then reinstall the bolt and washer / retaining ring.

Gate mounting

![](_page_21_Picture_10.jpeg)

Screw the gate mounting into place using two M8 bolts according to the assembly drawing.

Mounting plate for the swing arm bracket

![](_page_21_Picture_13.jpeg)

# FAAC DAAB INSTRUCTION MANUAL MT, MA2, MK2, M10 DRIVE UNIT Screw the bracket into place on the mounting plate using four M10 bolts. Adjust the swing arm so that it is always horizontal. 5 Adjust the mounting using the four set screws. 6 Screw in the short link arm between the outer swing arm mounting and the gate mounting using M12 bolts and washers.

Link arm

![](_page_22_Figure_2.jpeg)

![](_page_23_Picture_2.jpeg)

# DARB FAAC

## • Adjusting the drive unit

![](_page_24_Figure_3.jpeg)

WARNING Disengage the door/gate at the drive arm and ensure that it can be easily operated manually.

## DANGER

Before all safety devices are in operation and are correctly calibrated only hold to run operation is permitted.

![](_page_24_Picture_8.jpeg)

Ensure that the door/gate opens and closes to the correct position, i.e. that it does not press too hard on the surround or does not open completely. The leaves of the gate must line up with each other in the closed position which is important if there is a solenoid lock or striker. Adjust the limit positions by turning the limit cams on top of the drive unit output shaft. The upper cam is for adjusting the closed position and the lower for the open position.

• Disengagement Quick release

![](_page_24_Picture_11.jpeg)

Turn the release handle a half turn to disengage the door. Release handle

![](_page_24_Picture_13.jpeg)

Unscrew the release handle from the drive arm mounting to disengage the door.

![](_page_25_Picture_0.jpeg)

# **Electrical connection**

## • General

![](_page_25_Picture_4.jpeg)

WARNING Turn off the main circuit breaker before carrying out electrical work.

![](_page_25_Picture_6.jpeg)

## WARNING

All electrical work must be carried out by a qualified electrician.

## NOTE!

Check that the supply voltage and motor voltage are the same.

• Engaging the electric motor

![](_page_25_Picture_12.jpeg)

3-phase motor Star-coupled

![](_page_25_Figure_14.jpeg)

![](_page_25_Picture_15.jpeg)

3-phase motor Delta-coupled

![](_page_25_Picture_17.jpeg)

Assymetrical

![](_page_26_Picture_1.jpeg)

## • Limit positions

Terminal block on the limit position plate		
No. 1	Limit position Open (lower cam) C	
No. 2	Limit position Open (lower cam) NC	
No. 3	Limit position Close (upper cam) C	
No. 4	Limit position Close (upper cam) NC	
No. 5	Thermal switch (if used)	
No. 6	Thermal switch (if used)	
No. 7	Connection block for the anti-trap guard or solenoid etc.	
No. 8	Connection block for the anti-trap guard or solenoid etc.	

## Maintenance and service

• General

![](_page_26_Picture_6.jpeg)

WARNING Turn off the main circuit breaker before carrying out service and maintenance.

## NOTE!

## Check of safety circuits according to the Industrial Door Standard and national regulations

Since FAAC Nordic don't supply the complete machine, we refer to the instructions made by the supplier of the industrial door or gate. According to the Swedish authority "Boverket", the function of the safety arrangements shall be checked according to the instructions of the industrial door or gate supplier. If instructions are missing, a check of the safety functions shall be performed twice a year.

This must be documented in a log book.

Preventive maintenance must be performed depending of usage frequency and application; i.e. a big and heavy door or gate in a high frequency usage environment must be maintained more often than a small and light door/gate with low usage. The table below describes a medium size door/gate with medium frequency usage.

Openings/day	Maintenance interval *
< 100	24 months
100 - 200	12 months
200 - 500	6 months
> 500	3 months

\*) To ensure that the correct maintenance interval is chosen, the drive unit shall be checked 2-3 months after commissioning to decide which interval is required in the current installation.

Preventive maintenance includes the following points:

- Check that all bolts are tightened.
- Check the tension and condition of the V-belt (where applicable), adjust ocr change if necessary.
- Check that the release mechanism can be easily disengaged, lubricate if necessary.
- Lubricate the spherical link arm bearings with grease.
- Check the lubrication of the gearbox, see instructions pn the following page.

# Lubrication

Oil filled gearbox

![](_page_27_Picture_4.jpeg)

A drive unit with an oil-filled gearbox is lubricated using synthetic oil: Bechem Berusynth GP 150 or equivalent. Oil change is normally not necessary.

The M10 drive unit has two gear wheels under the gearbox. These must be lubricated using Molykote 165 LT at the intervals chosen according to previous page.

## Open gearbox

![](_page_27_Figure_8.jpeg)

MA2

A drive unit with an open gearbox must be lubricated at the intervals chosen according to previous page. Apply Molykote 165 LT onto the worm gears and worm screws.

## **Spare parts**

Contact FAAC Nordic AB with any queries or to order spare parts and accessories. Always give the serial number which is located on the inside of the control cabinet.

## **Fault search**

## • In the event of a blockage

If the door/gate cannot be operated manually using one of the normal control devices, use the manual release (see the chapter on disengagement). Disengagement means that the door/gate can be opened and closed manually without damaging the drive mechanism.

## • In the event of a collision

A collision can seriously damage the installation, always check the anti-trap function, load guard and that parts are intact before continuing to use the system. If spare parts are needed see the chapter on spare parts.

## • The motor is running but the gate is not moving

Check that the door/gate is not disengaged. If the installation is disengaged, try to contact the person who disengaged it to find out the reason for this. If the installation is not disengaged, check that the drive arm mounting and other mechanical components are intact.

![](_page_28_Picture_1.jpeg)

![](_page_29_Picture_0.jpeg)

![](_page_29_Picture_1.jpeg)